disassembly & recycling instructions **OM5**[™]

omseating

recommended tools	Safety Glasses Work Gloves Flat Head Screw Driver Phillips Screw Driver Socket Wrench Set Allen Wrench Set Hammer (Sledge preferred Pipe Wrench (24 inch pref Utility Knife Steel Putty Knife Magnet				
recyclable material	 A Base B Arm Frame C Seat Board D Polyback E Cylinder F Upright Bar G Nameplate 	- Plastic - Plastic - Steel - Plastic			B
rec	 H Back Frame H Back Frame J Swing Arm J Seat Frame K Mechanism Housing L Hardware 	- Plastic - Plastic - Plastic - Plastic	Ć.		

- Start by laying the chair on its back.
 Pull the casters off the base. Use a fi
 Separate the base (A) from the cylin
 For stool models, remove the footrin
 Remove the cylinder from the mecha
 Remove the arms from the arm frame
 After removing the arm frames, remote
 Locate four bolts holding the mecha
 Bemove the upright bar (F) from the
 - 2 Pull the casters off the base. Use a flat head screw driver if needed to pry them loose.
 - **3** Separate the base (\mathbf{A}) from the cylinder (\mathbf{E}) by striking the bottom of the cylinder housing with a hammer.
 - 4 For stool models, remove the footring from the cylinder by loosening the handwheel. If no handwheel is found, twist the entire footring.
 5 Remove the cylinder from the mechanism housing (K) using a pipe wrench to twist the piston.
 - 6 Remove the arms from the arm frames (\mathbf{B}) with a socket wrench then the arm frame from the seat frame (\mathbf{J}) with an allen wrench.
 - 7 After removing the arm frames, remove the hip bushings to separate the swing arm (\mathbf{I}) .
 - 8 Locate four bolts holding the mechanism housing to the seat frame, and remove with a allen wrench.
 - **9** Remove the upright bar (\mathbf{F}) from the mechanism housing with a socket wrench.
 - **10** With a screw driver, remove the polyback (\mathbf{D}) from the back frame (\mathbf{H}) and nameplate (\mathbf{G}) .
 - 11 Remove the fabric from the seat with a utility knife.
 - 12 Separate foam from the plastic seat board \bigcirc with putty knife.