


## Assembly & Installation Instructions:

ergonomics® <del>|</del>

Conform Static Single Display Pole Mounted Monitor Mount CONF-ST101-12PB-TPCG-S

#### Parts Included



#### **Tools Required:**




### MOUNT BASE & POLE ASSEMBLY—CLAMP MOUNT

- 1a.1 Place the Clamp Knob (G) on the %-16 × 3.50"L Hex Bolt (F)
- 1a.2 Place the 3/8 Washer (I) onto the Hex Bolt (F)
- **1a.3** Install the % Hex Nut (H) onto the Hex Bolt (F) and tighten to hold the knob in place
- **1a.4** Install the Bolt and Knob assembly into the Clamp Bracket (J)
- **1a.5** Attach the Clamp Pad (K) to the Hex Bolt as shown using the 6-32 ×  $\frac{5}{16}$ " Phillips Pan Head Screw (L)
- 1a.6 Set the Clamp Bracket Assembly aside
- **1a.7** Place the 12" Pole Base (A) on the rear edge of your worksurface
- **1a.8** From the underside, place the clamp bracket and knob assembly into the slots of the 12" Pole Base (A). Be sure the bracket is fully seated and tighten securely

**Note:** Place the Clamp Bracket Assembly up as high as possible into the Pole Base to make it easy to tighten

**1a.9** Install the Clamp Cover (B) as shown

**Note:** If your desk is against a wall or panel system where the bracket is not visible the Clamp Cover (B) is not needed and you can skip installing it




## MOUNT BASE & POLE ASSEMBLY—GROMMET MOUNT

- **1b.1** Remove the L-Bracket from the 12" Pole Base (A) by removing the 2 screws from the base using a #3 Phillips screwdriver. Set the L-bracket aside
- **1b.2** Install the ¾-16 × 4.50"L Stud (N) into the base at least 8 full turns as shown
- **1b.3** Place the Pole Base & Stud into the grommet hole location for attaching to your desk


**Note:** If there is no grommet location in your desk you can drill a hole as small as  $\frac{3}{6}$ " using a power drill and drill bit or you can use a hole saw and drill a larger hole up to 3" diameter to install the grommet mount option

**1b.4** From the underside, place the Grommet Mount Channel (M) onto the Stud (N) with the "U" facing up as shown. Place the % Washer (I) and the %-16 Hex Nut (H) onto the Stud (N) and tighten securely



# Workrite

ergonomics®



## ATTACH THE QUICK RELEASE BRACKET & INSTALL THE MONITOR

**Note:** Using the Quick Release Mount is optional. Your monitor can be attached directly to the VESA plate of the monitor mount if desired

**3.1** Locate the VESA Mount Pattern on the back of your monitor


**Note:** In some cases, the VESA mounting pattern is hidden by a removable cover or the monitor base. These must be removed to install the Quick Release or mount the monitor.

3.2 Mount the Quick Release (O) to the VESA mount on your monitor as shown with four (4) M4 Screws either (P), (Q), (R) or (S) and tighten securely

**Note:** Always use the shortest screws possible to avoid damaging the display by using screws that are too long

**Note:** In some case your monitor may require the use of the ¾" Spacers (T) to allow proper installation of the Quick Release (O)

**3.3** Aligning the Monitor with Quick Release onto the VESA Plate and then sliding down to lock in place as shown




# 4

### **CABLE MANAGEMENT**

**4.1** Place monitor cables into the cable retainers of the Pole support ring


**Note:** Make sure there is slack in the cables that allows movement to tilt and rotate the monitor without binding



## 5

### **ADJUSTING MONITOR HEIGHT**


- **5.1** Lift the monitor and mount off the Support Ring (C)
- **5.2** Loosen the knob and raise or lower the ring to the desired height and re-tighten
- **5.3** Lower the monitor mount and monitor back onto the support ring



## 6

### ADJUSTING MONITOR TILT

- **6.1** Locate the tilt adjustment bolt on the Monitor Mount
- **6.2** If the monitor tilt is too difficult to tilt loosen the tilt adjustment bolt using the  $\frac{3}{16}$ " Long Allen Wrench (V) until the monitor is easy to tilt but still holds in position after adjustments are made (do not over loosen)
- **6.3** If the monitor drops or is not holding tilt, tighten the tilt adjustment bolt using the  $^3/_{16}$ " Long Allen Wrench (V) until the monitor holds tilt but still allows tilt adjustments to be made easily (do not over tighten)



1500542 Rev A