r					
Model #		Operation #			
All		Back Pin Replacement			
Proces	s Description		Page		
Back Pi	in Replacment		1/2		
Work Content - Verify - TQC					
Step	Description				
1	Drive the back pin out of the chair from the inside using a punch/Allen key and a mallet. *				
2	Pull Pin from opposing side with fingers or if sticky, pliers work well. While removing Pin pinch the back frame and the lower back together to keep the holes aligned.				
3	Insert new pin into back and tap in gently using a mallet. The pin should slide in easily. ** Once seated a good firm tap should be given to the pin to insure that it is in completely.				
4	Repeat for other side.				
	* If changing pins special tool can b that must be return ** If pin is not goin instructions.	e requested rned upon jo	from the factory b completion.		

Rev #	Date
1	12/22/05

Drive Pin from here





Model # All		Operation # Back Pin Replacement			
Process Description			Page		
back spring			2/2		
Work Content - Verify - TQC					
Step	Description				
1	Insert spring R04-xxx into spring pocket and secure with silver bullet R04-710				
2	Repeat for other side.				
3	Align back and insert back pins				
4	Tap pins into place using a mallet as per step 3 and 4 on previous page.				

Rev #	Date
1	12/22/05

