

Lateral Slider

Installation Instructions

1. Remove the keyboard platform from the mechanism by unscrewing the four countersunk phillips screws and nuts shown.
2. Mount and secure the Lateral Slider to the mechanism using the four enclosed machine screws and the previously removed nuts.
3. Align the keyboard platform and secure it to the Lateral Slider using the four countersunk phillips screws.

