






Fits most 15.6" Laptops.



Components

	A	B	C	D	E	F
1	1x 	1x 	1x 	1x  5-sided Security Wrench	2x  M4x18mm	2x  M3x14mm

Tools Needed



WARNING! Do not use laptop for syncing while stored inside a closed Laptop Locker as it could raise the temperature high enough to cause product damage. Laptop Locker should be used for storage or charging only. Place the laptop on top of the Laptop Locker when connected to USB port for syncing.

For the latest User Installation Guide please visit: www.ergotron.com







User's Guide - English
 Guía del usuario - Español
 Manuel de l'utilisateur - Français
 Gebruikersgids - Deutsch
 Benutzerhandbuch - Nederlands
 Guida per l'utente - Italiano
 Användarhandbok - svenska
 ユーザーガイド : 日本語
 用户指南 : 汉语







www.ergotron.com
 USA 1-800-888-8458
 Europe +31 (0)33-45 45 600
 China 86-769-86018920


- 1** a. Remove the two screws holding the top on the cart or module.
b. Slide top off of cart or module.




- 2** a. Slide Laptop Locker onto cart or module.
b. Secure Locker with the 2 provided security screws.




- 3** a. Unlock Laptop Locker.
b. Open cover.
c. Attach security bracket.



- 4** Attach Laptop.
Route power cable from outlet, through hole in back of Locker and plug into laptop.



5 Close and lock Laptop Locker.




ENGLISH

For service and warranty visit www.ergotron.com

For local customer care phone numbers visit: <http://contact.ergotron.com>



NOTE: When contacting customer service, reference the serial number.



 © 2013 Ergotron, Inc.
All rights reserved.

While Ergotron, Inc. makes every effort to provide accurate and complete information on the installation and use of its products, it will not be held liable for any editorial errors or omissions (including those made in the process of translation from English to another language), or for incidental, special or consequential damages of any nature resulting from furnishing this instruction and performance of equipment in connection with this instruction. Ergotron, Inc. reserves the right to make changes in the product design and/or product documentation without notification to its users. For the most current product information, or to know if this document is available in languages other than those herein, please contact Ergotron. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written consent of Ergotron, Inc., 1181 Trapp Road, Eagan, Minnesota, 55121, USA. Patents Pending and Patented U.S. & Foreign. Ergotron is a registered trademark of Ergotron, Inc.

Americas Sales and Corporate Headquarters

St. Paul, MN USA
(800) 888-8458
+1-651-681-7600
www.ergotron.com
sales@ergotron.com

EMEA Sales

Amersfoort, The Netherlands
+31 33 45 45 600
www.ergotron.com
info.eu@ergotron.com

APAC Sales

Tokyo, Japan
www.ergotron.com
apaccustomerservice@ergotron.com

Worldwide OEM Sales

www.ergotron.com
info.oem@ergotron.com