INSTALLATION INSTRUCTIONS

COLUMN TUBE AND CEILING PLATE CMA-260

The optional CMA-260 column tube and ceiling plate are designed for attachment to the Chief ceiling mounts. The CMA-260 provides vertical adjustments in 3/4" increments when the column tube is telescoped over the ceiling plate tube and bolted through at the desired height.

WARNING: IMPROPER INSTALLATION MAY RESULT IN SERIOUS PERSONAL INJURY!

When mounting Chief Manufacturing accessories, the structural system and mounting method **MUST** be capable of supporting 5 times the combined weight of the total installation. The maximum weight to be installed on the ceiling plate is 500 pounds (226.8 Kg).

Unpack and check contents:

(1) Column Tube

(2) 1/4 - 20 Nylock Nuts

(1) Ceiling Plate Tube

(4) ¹/₄" Flatwashers

(2) ¹/₄ - 20 x 3¹/₄" Bolts

- (1) 5/32" Hex Wrench
- (4) 5/16" 18 Socket Set Screws

INSTALLATION INSTRUCTIONS

- 1. Securely install ceiling plate to ceiling or joists (see Figure 1). NOTE: SEE WARNING!!
- 2. Screw column tube firmly into the ceiling mount collar.
- 3. Slide the column tube over ceiling plate tube to desired height and cross bolt using two ¼" bolts, nuts and washers provided. Make sure nuts and screws are firmly tightened.
- 4. Install four 5/16" 18 set screws into holes offset from the cross bolt.
- 5. Follow ceiling mount instructions for installation and adjustment of the projector.




Figure 1. CMA-260 COLUMN TUBE AND CEILING PLATE