


PBL Adjustable Height Presentation Stand



Assembly Instructions

See back for important information


Adjustable Height Presentation Stand PBL

| Part | Drawing | Description | Qty | Part | Drawir | ng Description | Qty |
|-------|---|-----------------|------|------|----------|--------------------------------|-------|
| P-1 | | Leg Frame | 2 EA | | | Hardware List | ` |
| | | | | А | 9 | Flat Head Screw | 16 EA |
| | | | | В | | Interior Threaded Post | 8 EA |
| P-2 | | Stability Panel | 2 EA | С | | 3" Locking Casters (for Front) | 2 EA |
| P-3 | | Top Platform | 1 EA | D | | 3" Casters (for Back) | 2 EA |
| | | | | E | | Allen Wrench | 1 EA |
| P-4 | | Upper Insert | 2 EA | F | E | Caster Wrench | 1 EA |
| P-5 | | Laptop Platform | 1 EA | G | | Knob | 2 EA |
| Tools | Tools Required: Philips Head Screw Driver | | | | | | |

To Assemble:

- 1. Identify and Separate all the Parts and Hardware.
- 2. Place the Top Platform (P-3) with the insert nuts facing up. Attach 2 Upper Inserts (P-4) using 4 Flat Head screws (A) as shown in illustration # 1.


(Do not tighten the screws all the way).



Do not use unless all screws are tight. At least every six months, check all screws to be sure they are tight. If parts are missing, broken, damaged, or worn, stop use of the product until repairs are made by your dealer using factory authorized parts.




PBL Adjustable Height Presentation Stand Assembly Diagram



5. Attach Laptop Platform (P-5) to 2 Leg Frames (P-1) using 4 Flat Head screws (A).

Note: It is recommended that when attaching stability panels, loosely tighten until all four screws and thread posts are positioned before fully tightening with Allen Wrench.



Important

The Balt product you have purchased is guaranteed against material and workmanship defects. This guarantee extends 1 year from date of purchase.

Should this product fail to function satisfactorily under normal use due to defect or imperfection, the defective part or product will be replaced. Damage caused by common carriers during shipment is not included in this guarantee.

This guarantee sets forth all applicable guarantees and remedies. No other warranty, expressed or implied shall apply. Failure to follow instructions found in Important Information Section of Owner Sheet shall void the guarantee. Consequential or incidental damages and or costs are not refundable.

Toll-Free Customer Service

1-800-749-2258

Should you require assistance during assembly, please call our Customer Service Department Monday - Friday 8 a.m. - 5 p.m.

Central Standard Time