

SCREEN CONFIGURATION CHART

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Acer	32"	AT3220A	M6	12		none	
Acer	42"	AT4220	M6	12	multi	none	
Akai	32"	LCT3201AD	M5	55			1
Akai	32"	LCT3201TD	M5	55			1
Akai	32"	LCT3226	M5	55			1
Akai	32"	LCT3285	M5	55			1
Akai	37"	LCT3701AD	M5	55			1
Akai	37"	LCT3782TD	M5	55			1
Akai	37"	LCT37Z6TA	M5	55			1
Akai	42"	PDP4216M	M6	12	none	none	
Akai	42"	LCT42Z6TM	M6	12	none	none	
Akai	42"	PDP4225	M6	12	none	none	
Akai	42"	PDP4206EM	M6	12	none	none	
Akai	42"	PDP4249G	M6	20	multi	none	
Akai	42"	PDP4249ED	M6	20	multi	none	
Akai	42"	PDP4273M	M6	12	none	none	
Akai	42"	PDP4290	M8	40	none	8.7mm ID	
Akai	42"	PDP4294	M8	40	none	8.7mm ID	
Akai	42"	PDP4298ED	M8	40	none	8.7mm ID	
Akai	50"	PDP5073TM	M6	12	none	none	
Akira	42"	EMP 420	M5	25	multi	5.6mm ID	91
Akira	42"	EMP420A/B	M5	25	multi	5.6mm ID	91
Akira	42"	SV 4201	misc	misc	misc	misc	90
Akira	42"	SV 4201H	misc	misc	misc	misc	90
Akira	42"	SV-4202IQ	M8	40	none	8.7mm ID	91
Akira	50"	HPT-500AW	M8	40	none	8.7mm ID	91
Aomni	32"	AL321A7	M6	12	multi	none	
Aomni	32"	HL-3210V	M5	12	washer	none	
Aomni	32"	HL-3210VS	M5	12	multi	none	
AOC	42"	A42W64	M6	12	multi	none	5
AOC	42"	A42HD84	M6	12	multi	none	5
AOC	42"	A42W64AT4	M6	12	multi	none	5
Barco	40"	Solaris LC40	M8	25	none	none	18
Barco	40"	Solaris LC40-E	M8	25	none	none	18
Barco	40"	Solaris LC40-M	M8	25	none	none	18
Ben Q	42"	PDP7859	misc	misc	misc	misc	90
Ben Q	46"	PD46W1	M6	12	multi	none	5
Ben Q	46"	46W1-S	M6	12	multi	none	5
Boxlight	50"	PD5000	M8	40	none	8.7mm ID	91
Broksonic	32"	CCVG-3276	M4	12	washer	none	6
byd:sign	42"	d:4222	M8	40	none	8.7mm ID	91
byd:sign	42"	d:4232	M8	40	none	8.7mm ID	91
byd:sign	47"	d:4742M	M8	40	none	8.7mm ID	
byd:sign	47"	d:4742DII	M8	40	none	8.7mm ID	
byd:sign	50"	d:5032	M8	40	none	8.7mm ID	91
Chi Lin	32"	ST-HB32A4X	M6	12	none	none	
CHIMEI	32"	DTC-32MK	M6	12	none	none	
CHIMEI	37"	DTC-37MK	M6	12	none	none	
Christie	40"	FP40 (38-FP0001-0X)	M6	12	multi	none	
Clarity Visual	40"	SN-4025WX (Bobcat I)	1/4-20	1/2"	multi	none	20
Clarity Visual	40"	SN-4035WX (Bobcat II)	1/4-20	1/2"	multi	none	20
Clarity Visual	40"	SN-4045WX (Bobcat X)	1/4-20	1/2"	multi	none	20
Cornea Systems	42"	MP4205	M8	16	none	none	8
Curtis Mathes	26"	CMMX26	M4	12	washer	none	6
Curtis Mathes	32"	CMMX32	M4	12	washer	none	6
Daewoo	42"	DP-42GM	M5	12	multi	none	
Daewoo	42"	DP-42SM	M5	12	multi	none	
Daewoo	42"	DP-42WM	M5	12	multi	none	
Daewoo	42"	DSP-4210	misc	misc	misc	misc	90
Daewoo	42"	PD42S20W	M4	12	multi	none	
Daewoo	46"	PD46C10	M6	12	multi	none	5
Dell	32"	W3201C	M6	12	none	none	
Dell	37"	W3706MC	M6	12 or 20	multi	none	
Dell	37"	W3707C	M6	12	none	none	
Dell	42"	W4200	M8	40	none	8.7mm ID	91
Dell	42"	W4200ED	M8	40	none	8.7mm ID	91
Dell	42"	W4201C	M8	40	none	8.7mm ID	
Dell	50"	W5001C	M8	40	none	8.7mm ID	91
Digimate	42"	DG4200	M8	40	none	8.7mm ID	91
Dreamvision	42"	Revolution I	M4	12	multi	none	7

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Dukane	42"	P42HC	M5	12	multi	none	
Dukane	50"	P50	M8	16	none	none	
DWIN	50"	HD-150	M4	12	multi	none	7
Dynex	37"	DX-LCD37	M6	12		none	
EIZO	50"	P5070	M8	16	none	none	
EIZO	50"	P5071	M8	16	none	none	
Electrograph	32"	DTS32LTD	M5	12	multi	none	
Electrograph	42"	DTS-4230	M8	40	none	8.7mm ID	
Electrograph	42"	DTS42PT	M8	40	none	8.7mm ID	91
Electrograph	42"	DTS42W	M8	40	none	8.7mm ID	91
Element	32"	FLX-3202	M6	12	none	none	
Element	32"	FLX-3210	M6	12	none	none	
Element	37"	FLX-3710	M6	12	none	none	
Elo	32"	3220L	M6	12	none	none	
Emerson	32"	LC320EM8	M4	12	washer	none	6
Emprex	32"	HD-3201	M4	12	washer	none	6
Envision	32"	L32W698	M6	12	none	none	
Envision	42"	L42W761	M6	12		none	
Faroudja	42"	FPP-42HD20	M4	12	multi	none	7
Faroudja	42"	FPP-42HD25	M4	12	multi	none	7
Faroudja	50"	FPP-50HD20	M4	12	multi	none	7
Faroudja	50"	FPP-50HD25	M4	12	multi	none	7
Fujitsu	42"	P42HCA11WA	M8	15	none	none	
Fujitsu	42"	P42HCA11WH	M8	15	none	none	
Fujitsu	42"	P42HCA30WH	M8	15	none	none	
Fujitsu	42"	P42HHA10US	M8	15	none	none	
Fujitsu	42"	P42HHA10WS	M8	15	none	none	
Fujitsu	42"	P42HHA30WS	M8	15	none	none	
Fujitsu	42"	P42HHA40US	M8	15	none	none	91
Fujitsu	42"	P42HVA40	M8	15	none	none	91
Fujitsu	42"	P42VCA21UH	M8	15	none	none	
Fujitsu	42"	P42VCA30WH	M8	15	none	none	
Fujitsu	42"	P42VHA20US	M8	15	none	none	
Fujitsu	42"	P42VHA30WS	M8	15	none	none	
Fujitsu	42"	P42XHA40US	M8	15	none	none	
Fujitsu	42"	P42VHA51WS	M8	15	none	none	
Fujitsu	50"	P50XCA11UH	M8	15	none	none	
Fujitsu	50"	P50XCA30WH	M8	40	none	8.7mm ID	
Fujitsu	50"	P50XHA10US	M8	40	none	8.7mm ID	
Fujitsu	50"	P50XHA30WS	M8	40	none	8.7mm ID	
Fujitsu	50"	P50XHA40US	M8	25	none	none	91
Fujitsu	50"	P50XTA51US	M8	25	none	none	91
Fujitsu	50"	PDS-5001	M8	40	none	8.7mm ID	
Fujitsu	50"	PDS-5002	M8	40	none	8.7mm ID	
Fujitsu	50"	PDS-5003	M8	40	none	8.7mm ID	
Fujitsu	50"	PDS-5004	M8	40	none	8.7mm ID	
Fujitsu	55"	P55XHA30WS	M8	40	none	8.7mm ID	
Fujitsu	55"	P55XHA40US	M8	25	none	none	91
Gateway	42"	GTW-P42M102	M8	25	none	8.7mm ID	10
Gateway	42"	GTW-P42M203	M8	25	none	8.7mm ID	10
Gateway	42"	GTW-P42M303	M8	25	none	8.7mm ID	10
Gateway	42"	GTW-P42M403	M8	25	none	8.7mm ID	10
Gateway	42"	GTW-P42M504	M8	40	none	8.7mm ID	14
Gateway	46"	GTW-P46M103	M6	12	multi	none	5
Gateway	50"	GTW-P50M203	M8	40	none	15.9mm tall	1
Gateway	50"	GTW-P50M603	M8	40	none	15.9mm tall	1
H&B	32"	HL-3200V-N	M5	12	washer	none	
H&B	37"	HL-3700V-N	M5	12	washer	none	
H&B	42"	HP-4250B-N	M8	16	none	none	8
H&B	42"	HP-4250V-N	M8	16	none	none	8
H&B	50"	HP-5000B-N	M8	16	none	none	8
H&B	50"	HP-5000V-N	M8	16	none	none	8
H&B	50"	HP-5500V-N	M8	16	none	none	8
Haier	32"	H326BB	M6	12	none	none	
Hannspree	32"	JT01-32U1-000G	M6	12	none	none	
Harsper	32"	HPL-3210	M5	12	washer	none	
Harsper	42"	HP-4200	M8	16	none	none	8
Harsper	42"	HP-4250	M8	16	none	none	8
Harsper	50"	HP-5000	M8	16	none	none	8
HCI	32"	HC-TV32LC	M4	12	washer	none	6

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Hewlett Packard	32"	HP-LC3200N	M4	12	washer	none	6
Hewlett Packard	32"	LC3272N	M6	12	none	none	
Hewlett Packard	37"	HP-LC3700N	M4	12	washer	none	6
Hewlett Packard	37"	LC3772N	M6	12	none	none	
Hewlett Packard	42"	LC4276N	M6	12	none	none	
Hewlett Packard	42"	PE4200N	M8	40	none	8.7mm ID	
Hewlett Packard	42"	PL-4200N	M8	40	none	8.7mm ID	
Hewlett Packard	42"	PL4260N	M8	40	none	8.7mm ID	
Hewlett Packard	42"	SL4278N	M4	12	washer	none	6
Hewlett Packard	47"	LC4776N	M6	12	none	none	
Hewlett Packard	47"	SL4778N	M4	12	washer	none	6
Hewlett Packard	50"	PL-5000N	M8	40	none	8.7mm ID	
Hitachi	32"	32HDL51	M6	12	multi	none	17
Hitachi	32"	32HDT20	M6	12	multi	none	5
Hitachi	32"	32HDT50	M6	12	multi	none	5
Hitachi	32"	32HDT55	M6	12	multi	none	5
Hitachi	32"	32HDT60	M6	12	multi	none	5
Hitachi	32"	32PD5000	M6	12	multi	none	5
Hitachi	37"	37HDL52	M5	16	none	none	1
Hitachi	37"	CMP307SX	M6	12	multi	none	
Hitachi	37"	CMP307U	M6	12	multi	none	
Hitachi	37"	CMP307XU	M6	12	multi	none	
Hitachi	42"	42EDT41	M6	12	multi	none	
Hitachi	42"	42HDF52	M6	12	multi	none	
Hitachi	42"	42HDM70	M6	12	multi	none	
Hitachi	42"	42HDS52	M6	12	multi	none	
Hitachi	42"	42HDS69	M6	12	multi	none	
Hitachi	42"	42HDT20	M6	12	multi	none	
Hitachi	42"	42HDT50	M6	12	multi	none	
Hitachi	42"	42HDT51	M6	12	multi	none	
Hitachi	42"	42HDT52	M6	12	multi	none	
Hitachi	42"	42HDT55	M6	12	multi	none	
Hitachi	42"	42HDT70	M6	12	multi	none	
Hitachi	42"	42HDX60	M6	12	multi	none	
Hitachi	42"	42HDX62	M6	12	multi	none	
Hitachi	42"	42HDX99	M6	12	multi	none	5
Hitachi	42"	CMP402HDU	M6	12	multi	none	
Hitachi	42"	CMP4120HDU	M6	12	multi	none	
Hitachi	42"	CMP4121HDU,	M6	12	multi	none	
Hitachi	42"	CMP4201U	M6	12	multi	none	
Hitachi	42"	CMP4202U	M6	12	multi	none	
Hitachi	42"	CMP4203U	M6	12	multi	none	
Hitachi	42"	CMP420V1	M6	12	multi	none	
Hitachi	42"	CMP420V2	M6	12	multi	none	
Hitachi	42"	CMP4211,	M6	12	multi	none	
Hitachi	42"	CMP4211U,	M6	12	multi	none	
Hitachi	42"	CMP4212,	M6	12	multi	none	
Hitachi	42"	CMP4212U,	M6	12	multi	none	
Hitachi	50"	50HDA39	M8	25	none	8.7mm ID	
Hitachi	50"	50HDT50	M8	16	none	none	
Hitachi	50"	50HDT55	M8	16	none	none	
Hitachi	50"	50HDX60	M8	16	none	none	
Hitachi	50"	CMP5000WXE	M8	16	none	none	
Hitachi	50"	CMP5000WXU	M8	16	none	none	
Hy-Tek	32"	Tek Panel 32	M4	12	washer	none	6
Hyundai	32"	HQL320WR	M4	12	multi	none	6
Hyundai	42"	PD421	M8	40	none	8.7mm ID	91
Idex	42"	PDM4276PC	misc	misc	misc	misc	90
Iiyama	40"	PLL400W-B0X	M6	20	multi	none	
Iiyama	40"	PLL400W-B1X	M6	20	multi	none	
Iiyama	40"	PLL400W-B1XDL	M6	20	multi	none	
ILO	32"	3200	M6	12	none	none	
ILO	32"	32HA36	M6	12	none	none	
Integra	50"	PLA-50FP1	M4	12	multi	none	7
Integra	50"	PLA-50-V1	M4	12	multi	none	7
Jensen	32"	JE3207	M4	12	washer	none	6
Jensen	32"	JE3269	M4	12	washer	none	6
JVC	32"	LT-32E478	M6	12	none	none	
JVC	32"	LT-32E488	M6	12	none	none	
JVC	32"	LT32WX84	M5	12	multi	none	

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
JVC	32"	LT32X575	M5	12	multi	none	
JVC	32"	LT-32X667	M6	12	none	none	
JVC	37"	LT-37E478	M6	12	none	none	
JVC	37"	LT37X776	M5	12	multi	none	
JVC	40"	GM-H40L2GU	M6	12	none	none	
JVC	40"	LT40FN97	M5	12	washer	none	
JVC	40"	LT40X776	M5	12	multi	none	
JVC	42"	GD-V4200PZW	M5	12	multi	none	
JVC	42"	GD-V4210PCE	M5	12	multi	none	
JVC	42"	GD-V4210PZW	M5	12	multi	none	
JVC	42"	GD-V4211PZW	M5	12	multi	none	
JVC	42"	GD-V422U	M8	40	none	8.7mm ID	2
JVC	42"	GM-P420PCE	M5	12	multi	none	
JVC	42"	GM-P420U	M5	12	multi	none	
JVC	42"	GM-P420UG	M5	12	multi	none	
JVC	42"	GM-V42UG	M5	12	multi	none	
JVC	42"	LT-42E488	M6	12	none	none	
JVC	42"	LT-42X688	M6	12	none	none	
JVC	42"	PD-42V475	M5	20	multi	none	1 & 91
JVC	42"	PD-42V485	M5	20	multi	none	1 & 91
JVC	42"	PD-42WV74	M5	20	multi	none	1 & 91
JVC	42"	PD-42WX84	M5	20	multi	none	1 & 91
JVC	42"	PD-42X795	M5	20	multi	none	1 & 91
JVC	42"	PD-42X995	M5	20	multi	none	1 & 91
JVC	42"	VM-42WV74	M5	20	multi	none	1 & 91
JVC	42"	VM-42WX84	M5	20	multi	none	1 & 91
JVC	46"	LT-46FH97	M6	12	none	none	
JVC	46"	LT-46FN97	M6	12	none	none	
JVC	47"	LT-47X788	M6	12	none	none	
JVC	50"	GD-V501U	M8	40	none	8.7mm ID	2
JVC	50"	GD-V502U	M8	40	none	8.7mm ID	2
JVC	50"	PD-50X795	M5	20	multi	none	1 & 91
JVC	50"	PD-50X995	M5	20	multi	none	1 & 91
Klegg	55"	KP-5501	M8	40	none	15.9mm tall	1
Konka	32"	KDL32AT23U	M8	40	none	none	
Konka	37"	KDL37AT23U	M6	12	none	none	
Kortek	40"	KT-LS40W2	M8	40	none	8.7mm ID	
Kortek	42"	KT-LS42WS	M8	40	none	8.7mm ID	
LG	30"	RL-30LZ50	M4	12	washer	none	6
LG	30"	RZ-30LZ50	M4	12	washer	none	6
LG	32"	32LH1DC	M6	12	none	none	
LG	32"	32LG30	M4	12	washer	none	6
LG	32"	32LG40	M4	12	washer	none	6
LG	32"	32LG60	M4	12	washer	none	6
LG	32"	32LG70	M4	12	washer	none	6
LG	32"	32LX1D	M4	12	multi	none	6
LG	32"	32LX2D	M4	12	multi	none	6
LG	32"	32LX2R	M4	12	washer	none	6
LG	32"	L3200A	M6	12	multi	none	11
LG	32"	L3200AK	M6	12	multi	none	11
LG	32"	L3200T	M4	8	multi	none	1
LG	32"	L3200TC	M4	8	multi	none	1
LG	32"	L3200TK	M4	8	multi	none	1
LG	32"	M3201C	M4	8	washer	none	1
LG	32"	RU-32LZ30C	M4	12	multi	none	6
LG	32"	RU-32LZ50C	M4	12	multi	none	6
LG	37"	37LB1DA	M6	12	multi	none	11
LG	37"	37LC2D	M6	12	multi	none	11
LG	37"	37LC5DC	M6	12	multi	none	11
LG	37"	37LG30	M6	12	multi	none	11
LG	37"	37LG50	M6	12	multi	none	11
LG	37"	37LG60	M6	12	multi	none	11
LG	37"	37LP1D	M6	12	multi	none	11
LG	37"	DU-37LZ30	M5	25	multi	5.6mm ID	
LG	37"	DU-37LZ30C	M5	25	multi	5.6mm ID	
LG	37"	L3700A	M6	12	multi	none	11
LG	37"	L3700AK	M6	12	multi	none	11
LG	37"	L3700T	M6	12	multi	none	11
LG	37"	L3700TC	M6	12	multi	none	11
LG	37"	L3700TK	M6	12	multi	none	11

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
LG	37"	M3700C-BA	M6	12	multi	none	11
LG	37"	M3701C	M6	12	multi	none	11
LG	40"	MU-40PA10B	M5	25	multi	5.6mm ID	
LG	42"	42LB1DR	M6	12	multi	none	11
LG	42"	42LB1DRA	M6	12	multi	none	11
LG	42"	42LB5D	M6	12	multi	none	11
LG	42"	42LBX	M6	12	multi	none	11
LG	42"	42LC2D	M6	12	multi	none	11
LG	42"	42LC5DC	M6	12	multi	none	11
LG	42"	42LG30	M6	12	multi	none	11
LG	42"	42LG50	M6	12	multi	none	11
LG	42"	42LG60	M6	12	multi	none	11
LG	42"	42LG70	M6	12	multi	none	11
LG	42"	42LP1DC	M6	12	multi	none	11
LG	42"	42PB4D	M6	12	multi	none	11
LG	42"	42PC1DA	M6	12	multi	none	11
LG	42"	42PC3D	M6	12	multi	none	11
LG	42"	42PC3DV	M6	12	multi	none	11
LG	42"	42PC5D	M6	12	multi	none	11
LG	42"	42PC5DC	M6	12	multi	none	11
LG	42"	42PG20	M6	12	multi	none	11
LG	42"	42PM1M	M6	12	multi	none	11
LG	42"	42PM4M	M6	12	multi	none	11
LG	42"	42PX10	M5	25	multi	5.6mm ID	
LG	42"	42PX20	M5	25	multi	5.6mm ID	
LG	42"	42PX3DBV	M5	40	multi	28.6mm tall	12
LG	42"	42PX3DLV	M5	40	multi	28.6mm tall	12
LG	42"	42PX3DCV	M5	25	multi	5.6mm ID	91
LG	42"	42PX4D	M5	25	multi	5.6mm ID	91
LG	42"	42PX5D	M5	25	multi	5.6mm ID	91
LG	42"	42PX7DC	M5	40	multi	28.6mm tall	12
LG	42"	42PX8DC	M6	12	multi	none	11
LG	42"	DU-42LZ30	M5	25	multi	5.6mm ID	
LG	42"	DU-42PX10C	M5	25	multi	5.6mm ID	91
LG	42"	DU-42PX11	M5	25	multi	5.6mm ID	91
LG	42"	DU-42PX12X	M5	25	multi	5.6mm ID	91
LG	42"	DU-42PX12XC	M5	25	multi	5.6mm ID	91
LG	42"	DU-42PX12XD	M5	12	multi	none	14
LG	42"	DU-42PY10	M5	25	multi	5.6mm ID	91
LG	42"	DU-42PZ60	M5	25	multi	5.6mm ID	91
LG	42"	MP-42PZH12	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PM10/11	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PM12X	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ15B	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ41V	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ44V	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ90C	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ90H	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ90M	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ90V	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ90XC	M5	25	multi	5.6mm ID	91
LG	42"	MU-42PZ94V	M5	25	multi	5.6mm ID	91
LG	42"	RU-42PX10C	M5	25	multi	5.6mm ID	91
LG	42"	RU-42PX11	M5	25	multi	5.6mm ID	91
LG	42"	RU-42PZ61	M5	25	multi	5.6mm ID	91
LG	42"	RU-42PZ71	M5	25	multi	5.6mm ID	91
LG	42"	RU-42PZ90	M5	25	multi	5.6mm ID	91
LG	42"	RU-42PZ90V	M5	25	multi	5.6mm ID	91
LG	47"	47LB1	M6	12	multi	none	11
LG	47"	47LBX	M6	12	multi	none	11
LG	47"	47LG50	M6	12	multi	none	11
LG	47"	47LG60	M6	12	multi	none	11
LG	47"	47LG70	M6	12	multi	none	11
LG	47"	47LG90	M6	12	multi	none	11
LG	50"	50PC1DR	M6	12	multi	none	11
LG	50"	50PC1DRA	M6	12	multi	none	11
LG	50"	50PC3D	M6	12	multi	none	11
LG	50"	50PC5DC	M6	12	multi	none	11
LG	50"	50PG20	M6	12	multi	none	11
LG	50"	50PG30	M6	12	multi	none	11

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
LG	50"	50PG60	M6	12	multi	none	
LG	50"	50PM1M	M6	16	multi	5.6mm ID	
LG	50"	50PM1M	M6	16	multi	5.6mm ID	
LG	50"	50PX1D	M5	25	multi	5.6mm ID	91
LG	50"	50PX10	M5	25	multi	5.6mm ID	
LG	50"	50PX20	M5	25	multi	5.6mm ID	
LG	50"	50PX4DR-H	M5	25	multi	5.6mm ID	91
LG	50"	50PX5D	M5	25	multi	5.6mm ID	91
LG	50"	50PY20	M5	25	multi	5.6mm ID	
LG	50"	DU-50PM10C	M5	25	multi	5.6mm ID	91
LG	50"	DU-50PX10C	M5	25	multi	5.6mm ID	91
LG	50"	DU-50PY10	M5	25	multi	5.6mm ID	91
LG	50"	DU-50PZ60	M5	25	multi	5.6mm ID	91
LG	50"	DU-50PZ60H	M5	25	multi	5.6mm ID	91
LG	50"	MU-50PM10/11	M5	25	multi	5.6mm ID	91
LG	50"	MU-50PZ41	M5	25	multi	5.6mm ID	91
LG	50"	MU-50PZ41B	M5	25	multi	5.6mm ID	91
LG	50"	MU-50PZ41V	M5	25	multi	5.6mm ID	91
LG	50"	MU-50PZ90C	M5	25	multi	5.6mm ID	91
LG	50"	MU-50PZ90V	M5	25	multi	5.6mm ID	91
LG	50"	RU-50PZ61	M5	25	multi	5.6mm ID	91
LG	60"	60PM4M	M8	15	none	none	
LG	60"	60PC1D	M8	25	none	8.7mm ID	
LG	60"	60PG30	M8	25	none	8.7mm ID	
LG	60"	60PG60	M8	25	none	8.7mm ID	
LG	60"	DU-60PY10	M8	15	none	none	
LG	60"	DU-60PZ60	M8	15	none	none	
LG	60"	MU-60PZ10	M8	15	none	none	
LG	60"	MU-60PZ12	M8	15	none	none	
LG	60"	MU-60PZ90C	M8	15	none	none	
LG	60"	MU-60PZ90V	M8	15	none	none	
LG	60"	MU-60PZ95V	M8	15	none	none	
MAG INNOVISION	32"	MA32EF1AC	M6	12	none	none	
Magnavox	32"	32MF605W/17	M4	12	multi	none	6
Magnavox	37"	37MF321D/37	M6	12	none	none	
Magnavox	37"	37MF331D/37	M6	12	none	none	
Magnavox (Philips)	42"	42MF230A	M6	12	multi	none	5
Magnavox	42"	42MF337B	M6	12	none	none	
Magnavox	42"	42MF437B/37	M6	12	none	none	
Magnavox	42"	42MF531D	M6	12	none	none	
Magnavox (Philips)	42"	42MF7000	M8	40	none	8.7mm ID	91
Magnavox	47"	47MF437B/37	M6	12	none	none	
Magnavox	52"	52MF437S/37	M8	25	none	8.7mm ID	
Marantz	42"	PD4240D	M4	12	multi	none	7
Marantz	42"	PD4250D	M4	12	multi	none	7
Marantz	42"	PD4280	M4	12	multi	none	7
Marantz	42"	PD4290D	M4	12	multi	none	7
Marantz	42"	PD4292D	M4	12	multi	none	7
Marantz	42"	PD4293D	M4	12	multi	none	7
Marantz	42"	PD-4298HD	M6	12	multi	none	
Marantz	50"	PD-5010D	M4	12	multi	none	7
Marantz	50"	PD-5020D	M4	12	multi	none	7
Marantz	50"	PD5040D	M4	12	multi	none	7
MAXENT	32"	MX-32X3	M4	12	multi	none	6
MAXENT	42"	MX-42HPM20	M8	40	none	8.7mm ID	91
MAXENT	42"	MX-42V1	M8	40	none	8.7mm ID	91
MAXENT	42"	MX-42VM10	M8	40	none	8.7mm ID	91
MAXENT	42"	MX-42VM7	M8	40	none	8.7mm ID	91
MAXENT	42"	MX-42X1	M8	40	none	8.7mm ID	91
MAXENT	42"	MX-42X3	M8	40	none	8.7mm ID	91
MAXENT	42"	MX-42XL11	M8	40	none	8.7mm ID	91
MAXENT	42"	MX-42XM11	M8	40	none	8.7mm ID	14
MAXENT	50"	MX-50HPM20	M8	40	none	8.7mm ID	
MAXENT	50"	MX-50X1	M8	40	none	15.9mm tall	1
MAXENT	50"	MX-50X3	M8	40	none	8.7mm ID	
Maxx Products	32"	3200	M6	12	multi	none	91
Maxx Products	32"	TL3200	M4	12	multi	none	
Maxx Products	42"	4250	misc	misc	misc	misc	90
Maxx Products	42"	4250T	misc	misc	misc	misc	90
Maxx Products	42"	TruVision 42	M5	12	multi	none	

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Maxx Products	42"	TruVision 42HD	M8	40	none	8.7mm ID	2
Maxx Products	46"	4600	misc	misc	misc	misc	90
Maxx Products	50"	5000	misc	misc	misc	misc	90
Maxx Products	50"	TruVision 50HD	M8	40	none	8.7mm ID	
Memorex	32"	MLT3221	M6	12		none	
Mitsubishi	32"	LDT321V	M6	12	none	none	11
Mitsubishi	32"	MDT321S	M4	12	washer	none	6
Mitsubishi	37"	LDT371V	M6	12	none	none	11
Mitsubishi	37"	LT37132	M6	12	none	none	
Mitsubishi	40"	MLM400	M6	12	none	none	11
Mitsubishi	42"	LDT421V	M6	12	none	none	
Mitsubishi	42"	PD4225S	M5	25	multi	5.6mm ID	
Mitsubishi	46"	LT-46133	M6	12	none	none	11
Mitsubishi	46"	LT-46134	M6	12	none	none	11
Mitsubishi	46"	LT-46144	M6	12	none	none	11
Mitsubishi	46"	LT-46233	M6	12	none	none	11
Mitsubishi	46"	LT-46244	M6	12	none	none	11
Mitsubishi	50"	PD5010	M4	12	multi	none	7
Mitsubishi	50"	PD5030	M4	12	multi	none	7
Mitsubishi	52"	LT-52133	M6	15	multi	none	
Mitsubishi	52"	LT-52134	M6	15	multi	none	
Mitsubishi	52"	LT-52144	M6	15	multi	none	
Mitsubishi	52"	LT-52233	M6	15	multi	none	
Mitsubishi	52"	LT-52244	M6	15	multi	none	
Monovision	32"	PD3231	M6	12	multi	none	91
Monovision	46"	PWR-46MCS	M6	12	multi	none	5
Monovision	46"	PWV-46ACS-1	M6	12	multi	none	5
Monovision	46"	PWV-MCD1	M6	12	multi	none	5
NEC	32"	LCD3210-EU	M6	12	multi	none	11
NEC	32"	PV32-AVT	M6	12		none	11
NEC	37"	LCD3735WXM	M6	12	none	none	11
NEC	40"	LCD4000	M6	12	multi	none	11
NEC	40"	LCD4010	M6	12	multi	none	11
NEC	40"	LCD4020-BK-AV	M6	12	none	none	11
NEC	40"	LCD4020-BK-IT	M6	12	none	none	11
NEC	40"	LCD4020-2-AV	M6	12	none	none	11
NEC	40"	LCD4020-2-IT	M6	12	none	none	11
NEC	40"	M40	M6	12	multi	none	11
NEC	40"	PV40-AVT	M6	12	none	none	11
NEC	42"	PlasmaSync 4200W (PX-42M2A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 4205W (PX-42M3A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 4210W (PX-42M4A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42MP1 (PX-42VM1A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42MP2 (PX-42VM2A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42MP3 (PX-42VM3A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42MP4 (PX-42XM1A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42PD1 (PX-VP1A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42PD2 (PX-VP2A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42PD3 (PX-VP3A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42PD4 (PX-VP4A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VM3G	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VM5 (PX-42VM5A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VP4 (PX-42VP4A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VP4 (PX-42VP4PA)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VP4D (PX-42VP4DA)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VP4D (PX-42VP4DP-A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VP5 (PX-42VP5A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42VR5 (PX-42VR5A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42XM2 (PX-42XM2A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42XM2/S (PX-42XM2A/S)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42XM3 (PX-42XM3A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42XM5A (PX-42XM5A)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42XR (PX-42XR)	M4	12	multi	none	7
NEC	42"	PlasmaSync 42XR3 (PX-42XR3A)	M4	12	multi	none	7
NEC	46"	LCD4610	M6	12	multi	none	11
NEC	46"	LCD4610	M6	12	none	none	11
NEC	46"	LCD4620-BK-AV	M6	12	none	none	11
NEC	46"	LCD4620-BK-IT	M6	12	none	none	11
NEC	46"	LCD4620-2-AV	M6	12	none	none	11
NEC	46"	LCD4620-2-IT	M6	12	none	none	11

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
NEC	46"	M46	M6	12	multi	none	11
NEC	50"	PlasmaSync 50MP1 (PX-50XM1A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50MP2 (PX-50XM2A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50PD1 (PX-50VP1A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50PD2 (PX-50VP2A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50XM3 (PX-50XM3A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50XM3/S (PX-50XM3A/S)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50XM4 (PX-50XM4A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50XM5A (PX-50XM5A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50XR4 (PX-50XR4A)	M4	12	multi	none	7
NEC	50"	PlasmaSync 50XR5 (PX-50XR5)	M4	12	multi	none	7
Nexus	32"	NX3201	M4	12	washer	none	6
Norcent	32"	NVX32H DU	M4	12	multi	none	6
Norcent	42"	PT-4246HD	M6	12		none	11
NuVision	37"	NVX37H DU	M6	12	multi	none	11
NuVision	47"	47LCM1	M6	12	multi	none	11
NuVision	50"	PD 50	M8	40	none	8.7mm ID	
Olevia/Syntax	32"	232V	M4	12	washer	none	6
Olevia/Syntax	32"	432V	M4	12	washer	none	6
Olevia/Syntax	37"	237V	M4	12	washer	none	6
Olevia/Syntax	37"	437V	M4	12	washer	none	6
Olevia/Syntax	42"	242V	M6	12	none	none	
Olevia/Syntax	47"	747i	M4	12	washer	none	6
Optoma	32"	TC32LH1	M4	12	multi	none	5
Orion	32"	32RTC	M4	12	washer	none	6
Ovideon	32"	LC3210W	M4	12	multi	none	6
Ovideon	32"	LCS3230	M4	12	multi	none	6
Ovideon	32"	LCS3240	M4	12	multi	none	6
Ovideon	37"	LCS3730	M4	12	multi	none	6
Panasonic	32"	TC-32LE60	M4	12	washer	none	6
Panasonic	32"	TH-32LHD7U	M4	12	multi	none	
Panasonic	32"	TH-32LHD7UK	M4	12	multi	none	
Panasonic	32"	TC-32LX70	M4	12	washer	none	6
Panasonic	37"	PT-37P1	M8	40	none	8.7mm ID	
Panasonic	37"	PT-37PD4P	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PA20HD	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PA20U/P	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PD25U/P	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PHD8UK	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PH9UK	M8	25	none	none	
Panasonic	37"	TH-37PH10UK	M8	40	none	8.7mm ID	2
Panasonic	37"	TH-37PG9U	M8	25	none	none	
Panasonic	37"	TH-37PR9U	M8	25	none	none	
Panasonic	37"	TH-37PR10U	M8	25	none	none	
Panasonic	37"	TH-37PW5	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD4UZ	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD5	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD5UY	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD5UZ	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD6	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD6U	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD6UX	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD6UY	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD7UY	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PWD8UK	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PX25U/P	M8	40	none	8.7mm ID	2
Panasonic	37"	TH-37PX30/PE30	M8	40	none	8.7mm ID	2
Panasonic	37"	TH-37PX50U	M8	40	none	8.7mm ID	
Panasonic	37"	TH-37PX60U	M8	40	none	8.7mm ID	2
Panasonic	42"	PT-42P1	M8	40	none	8.7mm ID	
Panasonic	42"	PT-42PD1-P	M8	40	none	8.7mm ID	
Panasonic	42"	PT-42PD2-P	M8	40	none	8.7mm ID	
Panasonic	42"	PT-42PD3-P	M8	40	none	8.7mm ID	
Panasonic	42"	PT-42PHD4	M8	40	none	8.7mm ID	
Panasonic	42"	PT-42PHD4-P	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PA20	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PA20U/P	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PA25U/P	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PD25U/P	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PD50U	M8	40	none	8.7mm ID	

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Panasonic	42"	TH-42PD60U	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PHD5UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PHD6	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PHD6EX/ES	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PHD6UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PHD7UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PHD7WK/WS	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PHD8UK	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PHW5	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PH9UK	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PH10UK	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PG9U	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PR9U	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PR10U	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PS9UK	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PS10EK/ES	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PW4	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PW5	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PW5UZ	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PW6LZ	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD3	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD3U	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD4UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD5	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD5UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD6	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD6EX/BX	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD6UX	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD6UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD7UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD7WK/WS	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PWD8UK	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWD8UY	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PWP4UZ	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PX20U/P	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PX25U/P	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PX500U	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PX50U	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PX600U	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PX60U	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PX75	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PX77	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42XVS30	M8	40	none	8.7mm ID	
Panasonic	42"	TH-42PZ700U	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PZ80U	M8	40	none	8.7mm ID	2
Panasonic	42"	TH-42PZ85U	M8	40	none	8.7mm ID	2
Panasonic	46"	TH-46PZ80U	M8	40	none	8.7mm ID	2
Panasonic	46"	TH-46PZ85U	M8	40	none	8.7mm ID	2
Panasonic	46"	TH-46PZ85X	M8	40	none	8.7mm ID	2
Panasonic	50"	PT-50PD2-P	M8	40	none	8.7mm ID	
Panasonic	50"	PT-50PD3-P	M8	40	none	8.7mm ID	
Panasonic	50"	PT-50PD4-P	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PF9UK	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PF10EK	M8	40	none	8.7mm ID	2
Panasonic	50"	PT-50PHD4-P	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHD3U	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHD5U	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHD5UY	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHD6	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHDEX/BX	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHD6UY	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHD7UY	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHD7WK/WS	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PHD8UK	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PHW5	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PH9UK	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PH10EK/ES	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PH10UK	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PM50U	M8	40	none	8.7mm ID	
Panasonic	50"	TH-50PWD8UK	M8	40	none	8.7mm ID	

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Panasonic	50"	TH-50PX20U/P	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX25U/P	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX30U/P	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX500U/P	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX50U/P	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX6U	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX600U/P	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX75	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX77	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX700	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX80U	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PX80X	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PZ77U	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PZ700U	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PZ750U	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PZ80U	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PZ85U	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50PZ85X	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50XVS30	M8	40	none	8.7mm ID	2
Panasonic	50"	TH-50XVS30U/P	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PE75U	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PH10EK	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PH10UK	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PX600U	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PX60U	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PX75U	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PX700	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PZ700U	M8	40	none	8.7mm ID	2
Panasonic	58"	TH-58PZ750U	M8	40	none	8.7mm ID	2
Panasonic	32"	32FD9954	M5	25	multi	5.6mm ID	
PDi	32"	P32LCLD	M6	12		none	
PDi	32"	P32LCLD	M6	12	none	none	
Philips	32"	BDL3221V	M6	12	none	none	11
Philips	32"	32FW997	M5	25	multi	5.6mm ID	
Philips	32"	32HF5335D/27	M4	12	washer	none	6
Philips	32"	32HF5545D/27	M4	12	washer	none	6
Philips	32"	32HF7543	M4	12	washer	none	6
Philips	32"	32HF7945D/27	M4	12	washer	none	6
Philips	32"	32HF7955H/27	M4	12	washer	none	6
Philips	32"	32HF7965D/27	M4	12	washer	none	6
Philips	32"	32MF605W/17	M4	12	multi	none	6
Philips	32"	32PF4320	M4	12	washer	none	6
Philips	32"	32PF5320	M4	12	multi	none	6
Philips	32"	32PF5321D	M4	12	washer	none	6
Philips	32"	32PF7320A	M4	12	multi	none	6
Philips	32"	32PF7421D	M4	12	washer	none	6
Philips	32"	32PF9630A	M4	12	multi	none	6
Philips	32"	32PF9996	M5	12	multi	none	
Philips	37"	37FD9944	M5	25	multi	5.6mm ID	
Philips	37"	37FD9954/17	M5	25	multi	5.6mm ID	
Philips	37"	37PF7320A	M5	12	multi	none	16
Philips	37"	37PF9431D	M5	12	multi	none	16
Philips	37"	37PF9630A	M5	12	multi	none	16
Philips	37"	37PF9631D	M5	12	multi	none	16
Philips	37"	37PF9965	M5	25	multi	5.6mm ID	
Philips	37"	37PFL5322D	M6	12	none	none	
Philips	37"	37PFL7332D/37	M8	25	none	8.7mm ID	
Philips	37"	37PFL9632D/10	M8	25	none	8.7mm ID	
Philips	42"	BDH4241V	M8	40	none	8.7mm ID	
Philips	42"	BDS4241V	M8	40	none	8.7mm ID	
Philips	42"	42FD9934	M5	12	multi	none	
Philips	42"	42FD9935	M5	12	multi	none	
Philips	42"	42FD9944	M5	12	multi	none	
Philips	42"	42FD9954	M5	12	multi	none	
Philips	42"	42FX9020/37	M5	12	multi	none	
Philips	42"	42FW9020	M5	12	multi	none	
Philips	42"	42FW9030	M5	12	multi	none	
Philips	42"	42FW905	M5	12	multi	none	
Philips	42"	42FW9220/37	M5	12	multi	none	5
Philips	42"	42FW997	M5	12	multi	none	

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Philips	42"	42FW9975/37	M5	12	multi	none	
Philips	42"	42HF7945D/27	M8	25	none	8.7mm ID	
Philips	42"	42PF5321D/37	M5	12	multi	none	16
Philips	42"	42PF7320A	M5	12	multi	none	16
Philips	42"	42PF7321D/37	M5	12	multi	none	16
Philips	42"	42PF7421D	M5	12	multi	none	16
Philips	42"	42PF9431D/37	M5	12	multi	none	
Philips	42"	42PF9630A	M5	12	multi	none	16
Philips	42"	42PF9730A	M5	12	multi	none	16
Philips	42"	42PF9731D	M5	12	multi	none	
Philips	42"	42PF9831D	M5	12	multi	none	16
Philips	42"	42PF9936	M5	40	multi	31.8mm tall	1 & 91
Philips	42"	42PF9936D	M5	12	multi	none	
Philips	42"	42PF9956	M5	12	multi	none	5
Philips	42"	42PF9966	M5	12	multi	none	5
Philips	42"	42PF9976	M5	12	multi	none	5
Philips	42"	42PF9996	M5	12	multi	none	
Philips	42"	42PFL5332D	M8	25	none	8.7mm ID	
Philips	42"	42PFL7332D/37	M8	25	none	8.7mm ID	
Philips	42"	42PFL9900D	M8	25	none	8.7mm ID	
Philips	46"	BDS4611	M6	12	multi	none	5
Philips	47"	47PFL5432D	M8	25	none	8.7mm ID	
Philips	47"	47PFL7432D/37	M8	25	none	8.7mm ID	
Philips	47"	47PFL9732D/37	M8	25	none	8.7mm ID	
Philips	50"	BDH5021V/27	M8	40	none	8.7mm ID	
Philips	50"	50FD9955	M4	12	multi	none	7
Philips	50"	50FD9956	M5	12	multi	none	
Philips	50"	50PF7320	M5	12	multi	none	
Philips	50"	50PF7320A	M5	12	multi	none	
Philips	50"	50PF9431D	M5	12	multi	none	
Philips	50"	50PF9630A	M5	12	multi	none	
Philips	50"	50PF9956	M5	12	multi	none	
Philips	50"	50PF9966	M5	12	multi	none	
Philips	50"	50PF9986	M5	12	multi	none	
Philips	50"	BDH5011	M8	40	none	15.9mm tall	1
Philips	52"	52PFL7422D/37	M8	25	none	8.7mm ID	
Philips	52"	52PFL7432D/37	M8	25	none	8.7mm ID	
Philips	42"	PDP-424MV	M4	12	multi	none	
Pioneer	42"	PDP-425CMX	M8	16	none	none	
Pioneer	42"	PDP-427CMX	M8	16	none	none	
Pioneer	42"	PDP-4270HD	M8	16	none	none	
Pioneer	42"	PDP-4271HD	M8	16	none	none	
Pioneer	42"	PDP-4272HD	M8	16	none	none	
Pioneer	42"	PDP-4280HD	M8	16	none	none	
Pioneer	42"	PRO940HD	M8	16	none	none	
Pioneer	42"	PRO950HD	M8	16	none	none	
Pioneer	43"	PDP-4300	M8	16	none	none	
Pioneer	43"	PDP-4304	M8	16	none	none	
Pioneer	43"	PDP-4310HD	M8	16	none	none	
Pioneer	43"	PDP-4312	M8	16	none	none	
Pioneer	43"	PDP-4330HD	M8	16	none	none	
Pioneer	43"	PDP-433CMX	M8	16	none	none	
Pioneer	43"	PDP-433PU	M8	16	none	none	
Pioneer	43"	PDP-4340	M8	16	none	none	
Pioneer	43"	PDP-4341HD	M8	16	none	none	
Pioneer	43"	PDP-4345HD	M8	16	none	none	
Pioneer	43"	PDP-434CMX	M8	16	none	none	
Pioneer	43"	PDP-434PU	M8	16	none	none	
Pioneer	43"	PDP-4350HD	M8	16	none	none	
Pioneer	43"	PRO800HD	M8	16	none	none	
Pioneer	43"	PRO810HD	M8	16	none	none	
Pioneer	43"	PRO910	M8	16	none	none	
Pioneer	43"	PRO920HD	M8	16	none	none	
Pioneer	43"	PRO930HD	M8	16	none	none	
Pioneer	50"	MC-505HD	M8	16	none	none	
Pioneer	50"	PDK-50HW2	M8	16	none	none	
Pioneer	50"	PDP-5000EX	M8	16	none	none	
Pioneer	50"	PDP-50A5HD	M8	16	none	none	
Pioneer	50"	PDP-5016HD	M8	16	none	none	
Pioneer	50"	PDP-502MX	M8	16	none	none	
Pioneer	50"	PDP-5030HD	M8	16	none	none	

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Pioneer	50"	PDP-503CMX	M8	16	none	none	
Pioneer	50"	PDP-503HDE	M8	16	none	none	
Pioneer	50"	PDP-5040CMX	M8	16	none	none	
Pioneer	50"	PDP-5040HD	M8	16	none	none	
Pioneer	50"	PDP-5045HD	M8	16	none	none	
Pioneer	50"	PDP-504CMX	M8	16	none	none	
Pioneer	50"	PDP-5050HD	M8	16	none	none	
Pioneer	50"	PDP-5060HD	M8	16	none	none	
Pioneer	50"	PDP-507CMX	M8	16	none	none	
Pioneer	50"	PDP-5070HD	M8	16	none	none	
Pioneer	50"	PDP-5071HD	M8	16	none	none	
Pioneer	50"	PDP-5072HD	M8	16	none	none	
Pioneer	50"	PDP-5080HD	M8	16	none	none	
Pioneer	50"	PDP-V501MC	M8	16	none	none	
Pioneer	50"	PDP-V501X	M8	16	none	none	
Pioneer	50"	PDP-V502MX	M8	16	none	none	
Pioneer	50"	PDP-V503MX	M8	16	none	none	
Pioneer	50"	PDP-V503MXE	M8	16	none	none	
Pioneer	50"	PDP-V505HD	M8	16	none	none	
Pioneer	50"	PROFHD1	M8	16	none	none	
Pioneer	50"	PRO1000HD	M8	16	none	none	
Pioneer	50"	PRO1000HD1	M8	16	none	none	
Pioneer	50"	PRO1010HD	M8	16	none	none	
Pioneer	50"	PRO1110HD	M8	16	none	none	
Pioneer	50"	PRO1120HD	M8	16	none	none	
Pioneer	50"	PRO1130HD	M8	16	none	none	
Pioneer	50"	PRO1140HD	M8	16	none	none	
Pioneer	50"	PRO1150HD	M8	16	none	none	
Pioneer	42"	PX-42VP10	M8	40	none	8.7mm ID	91
PixelPro	42"	PX-42XP10	M8	40	none	8.7mm ID	91
PixelPro	50"	PX-50-XP10	M8	40	none	15.9mm tall	1
PixelPro	42"	PD42ED	M6	12	multi	none	5
Planar	37"	PD370	M6	12	none	none	
Planar	40"	M40L	M6	12	none	none	
Planar	42"	PD420	M6	12	none	none	
Planar	42"	PD42ED	M6	12	multi	none	5
Planar	42"	PDP 42B	M5	25	multi	5.6mm ID	
Planar	42"	PDP-42HD	M6	12	multi	none	5
Planar	47"	PD470	M6	12	none	none	
Planar	52"	PD520	M6	12	none	none	
Polaroid	26"	2611-TLXB	M6	12	none	none	
Polaroid	26"	FLM-2632	M6	12	none	none	
Polaroid	26"	FXM-2611H	M6	12	none	none	
Polaroid	32"	3211-TLXB	M6	12	none	none	
Polaroid	32"	FLM-323B	M6	12	none	none	
Polaroid	32"	FLM-3232	M6	12	none	none	
Polaroid	32"	FLM-3237	M6	12	none	none	
Polaroid	32"	FXM-3211H	M6	12	none	none	
Polaroid	32"	TDA-03211C	M6	12	none	none	
Polaroid	37"	FLM-3701	M4	12	multi	none	6
Polaroid	37"	FLM-3734B	M6	12	none	none	
Polaroid	37"	FXM-3711H	M6	12	none	none	
Polaroid	40"	4011-TLXB	M6	12		none	
Polaroid	40"	FXM-4011H	M6	12	none	none	
Polaroid	40"	TLA-04011C	M6	12	none	none	
Polaroid	46"	4641-TLXB	M6	12	none	none	
Polaroid	46"	TLA-04641C	M6	12	none	none	
Polaroid	50"	9350	M8	16	none	none	
Polyvision	42"	PS-42D8	M8	40	none	8.7mm ID	91
Prima	32"	RX-326	M4	12	multi	none	6
Pro View	40"	PA-40JK1A	M6	12	none	none	
Pro View	42"	MH-422HU	M8	40	none	8.7mm ID	91
Pro View	42"	MH-422HUB	M8	40	none	8.7mm ID	91
Pro View	42"	MH-422SU	M8	40	none	8.7mm ID	91
Pro View	42"	MH-422SUB	M8	40	none	8.7mm ID	91
Pro View	46"	MH4625U	M6	12	multi	none	5
Pro View	42"	PVDT42RW	M4	12	multi	none	
Pro Vision	42"	PVDT42WH	M4	12	multi	none	
Protron	32"	PLTV32C	M4	12	multi	none	6
Protron	32"	PLTV3250	M4	12	washer	none	6

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Protron	42"	PLTV4250	M4	12	washer	none	6
RCA	32"	L32WD12	M6	12	none	none	
RCA	32"	L32WD26D	M6	12	none	none	11
RCA	37"	L37WD12	M6	12	none	none	
RCA	42"	P42WHD33	M5	40	multi	28.6mm tall	12
RCA	42"	P42WHD35	M5	40	multi	28.6mm tall	12
RCA	42"	PR42300	M4	12	multi	none	7
RCA	50"	PHD-50300	M4	12	multi	none	7
RCA	50"	PHD-50500	M8	16	none	none	
RCA	32"	CR-32HD	M5	25	multi	5.6mm ID	
Revolution HD	32"	S32LTD	M5	12	multi	none	
Revolution HD	42"	S42PTD	M8	40	none	8.7mm ID	
Revolution HD	42"	S4225PTD	M8	40	none	8.7mm ID	
Revolution HD	50"	S50PTD	M8	40	none	8.7mm ID	
Revolution HD	50"	S5025PM	M8	40	none	8.7mm ID	
Runco	40"	CX-40HD	M5	12	multi	none	
Runco	42"	CW42HD	M4	12	multi	none	7
Runco	42"	CW42i	M4	12	multi	none	7
Runco	42"	PL42CX	M8	40	none	8.7mm ID	
Runco	42"	SP42	M8	16	none	none	
Runco	42"	SP42DHD	M8	16	none	none	
Runco	43"	CW43MC	M8	16	none	none	
Runco	43"	PL43HDX	M8	16	none	none	
Runco	46"	CX-46HD	M5	12	multi	none	
Runco	50"	CW50	M4	12	multi	none	7
Runco	50"	CW50MC	M8	16	none	none	
Runco	50"	PL-50C	M8	16	none	none	
Runco	50"	PL50HDX	M8	16	none	none	
Runco	50"	SP50	M8	16	none	none	
Runco	50"	SP50DHD	M8	16	none	none	
Sabre	32"	LCT320BKA	M4	12	washer	none	6
Sampo	32"	LME-32X8	M4	25	multi	5.6mm ID	
Sampo	37"	LME-37X8	M4	25	washer	6.5mm ID	
Sampo	42"	LME-42X8	M8	40	none	8.7mm ID	
Sampo	42"	PME-42S6	M8	40	none	8.7mm ID	91
Sampo	42"	PME-42S7	M8	40	none	8.7mm ID	91
Sampo	42"	PME-42X6	M8	40	none	8.7mm ID	91
Sampo	42"	PME-42X8	M8	40	none	8.7mm ID	91
Sampo	42"	PME-42X9	M8	40	none	8.7mm ID	
Sampo	42"	PME-42V8	M8	40	none	8.7mm ID	
Sampo	50"	PME-50X6	M8	40	none	8.7mm ID	91
Sampo	50"	PME-50X10	M8	40	none	8.7mm ID	
Samsung	32"	LN32A330	M6	12		none	11
Samsung	32"	LN32A450	M6	12		none	11
Samsung	32"	LN32A550	M6	12		none	11
Samsung	32"	LN32A550P3F	M6	12		none	11
Samsung	32"	LN-R3228W	M6	12	multi	none	11
Samsung	32"	LN-R327W	M6	12	multi	none	11
Samsung	32"	LN-R328W	M6	12	multi	none	11
Samsung	32"	LN-S3251D	M6	12	none	none	11
Samsung	32"	LN-S3251HD	M6	12	none	none	11
Samsung	32"	LN-S3296D	M6	12	none	none	11
Samsung	32"	LN-T325H	M6	12	none	none	11
Samsung	32"	LN-T3232H	M6	12	none	none	11
Samsung	32"	LN-T3242H	M6	12	none	none	11
Samsung	32"	LN-T3242HX	M6	12	none	none	11
Samsung	32"	LN-T3253H	M6	12	none	none	11
Samsung	32"	LN-T3253HT	M6	12	none	none	11
Samsung	32"	LN-T3253HX	M6	12	none	none	11
Samsung	32"	SyncMaster 320P	M6	12	none	none	11
Samsung	37"	LN37A330	M6	12		none	11
Samsung	37"	LN37A450	M6	12		none	11
Samsung	37"	LN37A530	M6	12		none	11
Samsung	37"	LN37A550	M6	12		none	11
Samsung	37"	LN37A550P3F	M6	12		none	11
Samsung	37"	LN-T375H	M6	12	none	none	11
Samsung	37"	LN-T3732H	M6	12	none	none	11
Samsung	40"	400DXN	M6	12	none	none	
Samsung	40"	LN40A330	M6	12	none	none	11
Samsung	40"	LN40A450	M6	12	none	none	11

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Samsung	40"	LN40A550	M6	12	none	none	11
Samsung	40"	LN40A550P3F	M6	12	none	none	11
Samsung	40"	LN40A650	M6	12	none	none	11
Samsung	40"	LN-R408D	M6	12	none	none	11
Samsung	40"	LN-S4051D	M6	12	none	none	11
Samsung	40"	LN-S4051HD	M6	12	none	none	11
Samsung	40"	LN-S4095D	M6	12	none	none	11
Samsung	40"	LN-S4096D	M6	12	none	none	11
Samsung	40"	LN-T405H	M6	12	none	none	11
Samsung	40"	LN-T4032H	M6	12	none	none	11
Samsung	40"	LN-T4042H	M6	12	none	none	11
Samsung	40"	LN-T4042HX	M6	12	none	none	11
Samsung	40"	LN-T4046F	M6	12	none	none	11
Samsung	40"	LN-T4053H	M6	12	none	none	11
Samsung	40"	LN-T4053HT	M6	12	none	none	11
Samsung	40"	LN-T4053HX	M6	12	none	none	11
Samsung	40"	LN-T4061F	M6	12	none	none	11
Samsung	40"	LN-T4065F	M6	12	none	none	11
Samsung	40"	LN-T4066F	M6	12	none	none	11
Samsung	40"	LN-T4069F	M6	12	none	none	11
Samsung	40"	LN-T4071	M6	12	none	none	11
Samsung	40"	LN-T4081	M6	12	none	none	11
Samsung	40"	LN-T4081F	M6	12	none	none	11
Samsung	40"	SyncMaster 400P	M8	25	none	8.7mm ID	
Samsung	40"	SyncMaster 400Pn	M6	12	multi	none	11
Samsung	40"	SyncMaster 400PX	M6	12	none	none	11
Samsung	42"	HPN4239	M8	40	none	8.7mm ID	
Samsung	42"	HP-P4261	M8	40	none	8.7mm ID	
Samsung	42"	HP-R4252	M8	25	none	8.7mm ID	
Samsung	42"	HP-R4262	M8	25	none	8.7mm ID	
Samsung	42"	HP-R4272	M8	25	none	8.7mm ID	
Samsung	42"	HP-S4233	M8	25	none	8.7mm ID	
Samsung	42"	HP-S4273	M8	25	none	8.7mm ID	
Samsung	42"	HP-T4254	M8	25	none	8.7mm ID	
Samsung	42"	HP-T4234	M8	25	none	8.7mm ID	
Samsung	42"	HP-T4264	M8	25	none	8.7mm ID	
Samsung	42"	PN42A450	M8	25	none	8.7mm ID	
Samsung	42"	PPM42H3	M8	40	none	8.7mm ID	
Samsung	42"	PPM42M5H	M6	12	multi	none	11
Samsung	42"	PPM42M5S	M8	25	none	8.7mm ID	
Samsung	42"	PPM42M6SB	M8	25	none	8.7mm ID	
Samsung	42"	PPM42S2	misc	misc	misc	misc	90
Samsung	42"	PPM42S3	M8	40	none	8.7mm ID	
Samsung	42"	PPM42S3Q	M8	40	none	8.7mm ID	
Samsung	42"	PPM42S3X	M8	40	none	8.7mm ID	
Samsung	42"	PS-42P3ST	M8	40	none	8.7mm ID	
Samsung	42"	SPD-42P1SM	M8	25	none	8.7mm ID	
Samsung	42"	SPK-4215M	M8	25	none	8.7mm ID	
Samsung	42"	SPL4225K	misc	misc	misc	misc	90
Samsung	42"	SPN4235	M8	40	none	8.7mm ID	
Samsung	42"	SP-P4231	M8	40	none	8.7mm ID	
Samsung	42"	SP-P4251	M8	40	none	8.7mm ID	
Samsung	42"	SP-R4212	M8	25	none	8.7mm ID	
Samsung	42"	SP-R4232	M8	25	none	8.7mm ID	
Samsung	42"	SP-R4243	M8	25	none	8.7mm ID	
Samsung	42"	SP-S4223	M8	25	none	8.7mm ID	
Samsung	46"	460DXN	M6	12	none	none	
Samsung	46"	LN46A550	M6	12		none	11
Samsung	46"	LN46A550P3F	M6	12		none	11
Samsung	46"	LN46A650	M6	12		none	11
Samsung	46"	LN-S4692D	M8	25	none	8.7mm ID	
Samsung	46"	LN-S4695D	M8	25	none	8.7mm ID	
Samsung	46"	LN-S4696D	M8	25	none	8.7mm ID	
Samsung	46"	LN-T4642F	M8	25	none	8.7mm ID	
Samsung	46"	LN-T4642H	M8	25	none	8.7mm ID	
Samsung	46"	LN-T4661F	M8	25	none	8.7mm ID	
Samsung	46"	LN-T4665FX	M8	25	none	8.7mm ID	
Samsung	46"	LN-T4665FX	M8	25	none	8.7mm ID	
Samsung	46"	LN-T4669F	M8	25	none	8.7mm ID	
Samsung	46"	LN-T4681F	M8	25	none	8.7mm ID	

If your screen model is not listed below please check www.peerlessmounts.com for the latest version of this chart.

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Samsung	46"	SyncMaster 460P	M6	12	multi	none	11
Samsung	46"	SyncMaster 460Pn	M6	12	multi	none	11
Samsung	46"	SyncMaster 460PX	M6	12	none	none	11
Samsung	50"	FP-T5084	M8	25	none	8.7mm ID	
Samsung	50"	HPL5025	misc	misc	misc	misc	90
Samsung	50"	HPL5025M	misc	misc	misc	misc	90
Samsung	50"	HPN5039	M8	40	none	8.7mm ID	
Samsung	50"	HP-P5031	M8	40	none	8.7mm ID	
Samsung	50"	HP-P5071	M8	40	none	8.7mm ID	
Samsung	50"	HP-R5012	M8	25	none	8.7mm ID	
Samsung	50"	HP-R5052	M8	25	none	8.7mm ID	
Samsung	50"	HP-R5072	M8	25	none	8.7mm ID	
Samsung	50"	HP-S5033	M8	25	none	8.7mm ID	
Samsung	50"	HP-S5053	M8	25	none	8.7mm ID	
Samsung	50"	HP-S5073	M8	25	none	8.7mm ID	
Samsung	50"	HP-T5034	M8	25	none	8.7mm ID	
Samsung	50"	HP-T5044	M8	25	none	8.7mm ID	
Samsung	50"	HP-T5054	M8	25	none	8.7mm ID	
Samsung	50"	PN50A450	M8	25	none	8.7mm ID	
Samsung	50"	PN50A550	M8	25	none	8.7mm ID	
Samsung	50"	PN50A650	M8	25	none	8.7mm ID	
Samsung	50"	PPM50H2	M8	40	none	8.7mm ID	
Samsung	50"	PPM50H3	M8	40	none	8.7mm ID	
Samsung	50"	PPM50H3Q	M8	40	none	8.7mm ID	
Samsung	50"	PPM50M5H	M6	12	multi	none	11
Samsung	50"	SPD-50P2HM	misc	misc	misc	misc	90
Samsung	52"	LN52A550	M8	25	none	8.7mm ID	
Samsung	52"	LN52A550P3F	M8	25	none	8.7mm ID	
Samsung	52"	LN52A650	M8	25	none	8.7mm ID	
Samsung	52"	LN52A750	M8	25	none	8.7mm ID	
Samsung	52"	LN-T5265F	M8	25	none	8.7mm ID	
Samsung	52"	LN-T5281F	M8	25	none	8.7mm ID	
Samsung	52"	LN-T5265FX	M8	25	none	8.7mm ID	
Samsung	52"	LN-S5296D	M8	25	none	8.7mm ID	
Samsung	57"	LN-S5797D	M8	15	none	none	
Samsung	58"	FP-T5884	M8	25	none	8.7mm ID	
Samsung	58"	FP-T5894	M8	25	none	8.7mm ID	
Sansui	32"	HDLCDVD320	M4	12	washer	none	6
Sanyo	37"	DP37647	M6	12	none	none	
Sanyo	42"	42LM4WPN	M6	12	none	none	11
Sanyo	42"	PDP-42WE1	misc	misc	misc	misc	90
Sanyo	42"	PDP-42WV1ASB	M8	40	none	8.7mm ID	
Sanyo	32"	X32SV-NAGA II	M6	12	none	none	
Sceptre	42"	X42GV-NAGA	M6	12 or 20	multi	none	
Sceptre	32"	LC-32D5U	M6	12	multi	none	
Sceptre	42"	X42GV-KOMODO	M6	12	none	none	11
Sharp	32"	LC-32D7U	M6	12	multi	none	
Sharp	32"	LC-32DA5U	M6	12	multi	none	11
Sharp	32"	LC-32D40U	M6	12	none	none	
Sharp	32"	LC-32D41U	M6	12	none	none	
Sharp	32"	LC-32D43U	M6	12	none	none	
Sharp	32"	LC-32D50U	M6	12	none	none	
Sharp	32"	LC-32G4U	M6	30	multi	none	
Sharp	32"	LC-32GA5U	M6	12	multi	none	
Sharp	32"	LC-32GD4U	M6	12	multi	none	
Sharp	32"	LC-32GD6U	M6	12	multi	none	
Sharp	32"	LC-32GP1U	M6	12	none	none	
Sharp	32"	LC-32HT2U	M6	12	none	none	
Sharp	32"	LC-32HT3U	M6	12	none	none	
Sharp	32"	LC-32M41U	M6	12	none	none	
Sharp	32"	LC-32SH10U	M6	12	none	none	
Sharp	32"	LC-32SH20U	M6	12	multi	none	
Sharp	32"	LC-C3242U	M6	12	none	none	
Sharp	37"	LC-37D40U	M6	12	multi	none	
Sharp	37"	LC-37D42U	M6	12	none	none	
Sharp	37"	LC-37D43U	M6	12	none	none	
Sharp	37"	LC-37D4UJ	M6	12	none	none	
Sharp	37"	LC-37D5U	M6	12	multi	none	
Sharp	37"	LC-37D7U	M6	12	multi	none	
Sharp	37"	LC-37D90U	M6	12	none	none	

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Sharp	37"	LC-37G4U	M6	30	multi	none	
Sharp	37"	LC-37GB5U	M6	12	multi	none	
Sharp	37"	LC-37GD4U	M6	12	multi	none	
Sharp	37"	LC-37GD6U	M6	12	multi	none	
Sharp	37"	LC-37GP1U	M6	12	none	none	
Sharp	37"	LC-37HT3U	M6	12	multi	none	
Sharp	37"	LC-37HV4U	M6	20	multi	none	
Sharp	37"	LC-37HV6U	M6	20	multi	none	
Sharp	37"	LC-M3700	M6	12	multi	none	11
Sharp	40"	LC-40C32U	M6	12	none	none	
Sharp	40"	LC-40C37U	M6	12	none	none	
Sharp	40"	LC-40C45U	M6	12	none	none	
Sharp	42"	LC-42BT10U	M6	12	none	none	
Sharp	42"	LC-42D43U	M6	12	none	none	
Sharp	42"	LC-42D62U	M6	12	none	none	
Sharp	42"	LC-42D82U	M6	12	none	none	
Sharp	42"	LC-42D92U	M6	12	none	none	
Sharp	42"	LC-42HT3U	M6	12	none	none	
Sharp	43"	PZ-43HV2U	M8	16	none	none	
Sharp	45"	LC-45D40U	M6	12	none	none	
Sharp	45"	LC-45GD4U	M6	12	multi	none	11
Sharp	45"	LC-45GD6U	M6	12	multi	none	11
Sharp	45"	LC-45GX6U	M6	30	multi	none	
Sharp	45"	PN-455	M6	12	multi	none	
Sharp	46"	LC-46D43U	M6	12	none	none	
Sharp	46"	LC-46D62U	M6	12	none	none	
Sharp	46"	LC-46D64U	M6	12	none	none	
Sharp	46"	LC-46D82U	M6	12	none	none	
Sharp	46"	LC-46D92U	M6	12	none	none	
Sharp	46"	LC-60C46U	M6	12	none	none	
Sharp	46"	PN-465U	M6	12	none	none	
Sharp	46"	PN-465U-P	M6	12	none	none	
Sharp	50"	LC-PD50U	M8	16	none	none	
Sharp	50"	PZ-50HV2U	M8	16	none	none	
Sharp	52"	LC-52D62U	M6	12	none	none	
Sharp	52"	LC-52D64U	M6	12	none	none	
Sharp	52"	LC-52D82U	M6	12	none	none	
Sharp	52"	LC-52D92U	M6	12	none	none	
Sharp	52"	LC-60C52U	M6	12	none	none	
Sharp	52"	PN-525U	M6	12	none	none	
Sony	32"	FWD-32LX1	M6	12	multi	none	3
Sony	32"	FWD-32LX2F/B	M6	12	multi	none	3
Sony	32"	KDL-32L4000	M6	30		none	
Sony	32"	KDL-32M3000	M6	30		none	
Sony	32"	KDL-32M4000	M6	30		none	
Sony	32"	KDL-32S2000	M6	12		none	11
Sony	32"	KDL-32S2010	M6	12		none	11
Sony	32"	KDL-32S3000	M6	30		none	
Sony	32"	KDL-32SL130	M6	30		none	
Sony	32"	KDL-32XBR4	M6	30		none	
Sony	32"	KDL-32XBR6	M6	30		none	
Sony	32"	KDL-32XBR950	M5	25	multi	5.6mm ID	
Sony	32"	KDL-V32XBR1	M6	30	none	none	
Sony	32"	KDL-V32XBR2	M6	30	none	none	
Sony	32"	KE-32TS2	M5	35	multi	15.9mm tall	1 & 91
Sony	32"	KLV-32M1	M4	12	multi	none	
Sony	32"	KLV-32S200A	M6	30	none	none	
Sony	32"	KZ-32TS1	M5	35	multi	15.9mm tall	1 & 91
Sony	32"	KZ-32TS1U	M5	35	multi	15.9mm tall	1 & 91
Sony	32"	LMD-322	misc	misc	misc	misc	3
Sony	32"	PFM-32C1	misc	misc	misc	misc	3
Sony	37"	KDE-37XS955	M5	25	multi	5.6mm ID	
Sony	37"	KE-37XS910	M5	12	multi	none	22
Sony	40"	FWD-40LX1	misc	misc	misc	misc	3
Sony	40"	FWD-40LX2F/B	misc	misc	misc	misc	3
Sony	40"	KDL-V40XBR1	M6	12	none	none	
Sony	40"	KDL-40D3000	M6	20	none	none	
Sony	40"	KDL-40S20L1	M5	12	washer	none	22
Sony	40"	KDL-40S2010	M5	12	washer	none	22
Sony	40"	KDL-40S2400	M5	12	washer	none	22

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Sony	40"	KDL-40V2500	M6	12		none	
Sony	40"	KDL-40S3000	M6	20	none	none	
Sony	40"	KDL-40XBR4	M6	20	none	none	
Sony	40"	KDL-40XBR5	M6	20	none	none	
Sony	40"	KLV-40S200A	M6	20	none	none	
Sony	42"	FWD-42LX1	misc	misc	misc	misc	3
Sony	42"	FWD42PV1/S	misc	misc	misc	misc	3
Sony	42"	FWD-42PX2	misc	misc	misc	misc	3
Sony	42"	KDE-42XBR950	M5	12	multi	none	21
Sony	42"	KDE-42XS955	M5	25	multi	5.6mm ID	
Sony	42"	KDL-42XBR950	M5	12	multi	none	21
Sony	42"	KE42M1	M5	12	multi	none	
Sony	42"	KE42TS2	M4	25	multi	5.6mm ID	91
Sony	42"	KE42TS2U	M4	25	multi	5.6mm ID	91
Sony	42"	KE-42XBR900	M5	12	multi	none	
Sony	42"	KE-42XS910	M5	12	multi	none	
Sony	42"	KZ-42TS1	M4	25	multi	5.6mm ID	91
Sony	42"	KZ-42TS1J	M4	25	multi	5.6mm ID	91
Sony	42"	KZ-42TS1U	M4	25	multi	5.6mm ID	91
Sony	42"	PFM-42B1	misc	misc	misc	misc	3
Sony	42"	PFM-42B1U	misc	misc	misc	misc	3
Sony	42"	PFM-42B2	misc	misc	misc	misc	3
Sony	42"	PFM-42B2H	misc	misc	misc	misc	3
Sony	42"	PFM-42V1	misc	misc	misc	misc	3
Sony	42"	PFM-42X1	misc	misc	misc	misc	3
Sony	46"	KDL-46S2000	M6	20	none	none	
Sony	46"	KDL-46S2010	M6	12	none	none	
Sony	46"	KDL-46V2500	M5	16			
Sony	46"	KDL-46V3000	M6	20	none	none	
Sony	46"	KDL-46XBR2	M6	20	multi	none	
Sony	46"	KDL-46XBR3	M6	20	multi	none	
Sony	46"	KDL-46XBR4	M6	20	none	none	
Sony	46"	KDL-46XBR5	M6	20	none	none	
Sony	50"	FWD-50PX1	misc	misc	misc	misc	3
Sony	50"	FWD-50PX2	misc	misc	misc	misc	3
Sony	50"	KDE-50XBR950	M5	12	multi	none	21
Sony	50"	KDE-50XS955	M5	25	multi	5.6mm ID	
Sony	50"	KE-50XBR900	M5	12	multi	none	21
Sony	50"	KE-50XS910	M5	12	multi	washer	22
Sony	50"	PFM50C1/C1E	misc	misc	misc	misc	3
Sony	52"	KDL-52W3000	M6	12	none	none	
Sony	52"	KDL-52XBR2	M6	20	none	none	
Sony	52"	KDL-52XBR3	M6	20	none	none	
Sony	52"	KDL-52XBR4	M6	12	none	none	
Sony	52"	KDL-52XBR5	M6	12	none	none	
Sony	55"	KDE-55XBR950	M5	12	multi	none	21
Sony	32"	SEPD3200	M6	12	multi	none	91
Studio Experience	32"	SEPD3231	M6	12	multi	none	91
Studio Experience	46"	SEPD4600	M6	12	multi	none	5
Studio Experience	50"	SEPD5000	M8	40	none	8.7mm ID	91
Studio Experience	42"	HD4208TIII-PDP	M6	25	multi	8.7mm ID	
SVA	42"	HD4208TVI-PDP	M6	25	multi	8.7mm ID	
SVA	42"	HD4208UII	M6	25	multi	8.7mm ID	
Sylvania	37"	LC370SS8	M6	12	none	none	
Sylvania	42"	6842PEM	M8	16	none	none	
Sylvania	42"	6842PFM	M8	16	none	none	
Syntax/Olevia	32"	332H	M4	12	washer	none	6
Syntax/Olevia	32"	532H	M4	12	washer	none	6
Syntax/Olevia	32"	LT32HV	M4	12	washer	none	6
Syntax/Olevia	32"	LT32HVE	M4	12	washer	none	6
Syntax/Olevia	32"	LT32HVM	M4	12	washer	none	6
Syntax/Olevia	37"	337H	M4	12	washer	none	6
Syntax/Olevia	37"	537H	M4	12	washer	none	6
Syntax/Olevia	37"	LT37HV	M4	12	washer	none	6
Syntax/Olevia	37"	LT37HVE	M4	12	washer	none	6
Syntax/Olevia	37"	LT37HVi	M4	12	washer	none	6
Syntax/Olevia	42"	342i	M6	12	none	none	
Syntax/Olevia	42"	542i	M6	12	none	none	
Syntax/Olevia	42"	742i	M4	12	washer	none	6
Syntax/Olevia	42"	LT42HVI	M6	12	none	none	

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
Syntax/Olevia	50"	LCT50HV	M4	12	multi	none	6
Syntax/Olevia	32"	V32FLBBU02	M4	12	washer	none	6
Tatung	42"	P42BLTL	M5	25	multi	5.6mm ID	91
Tatung	42"	P42BSMT	M6	12	multi	none	5
Tatung	42"	P42HSMT	M6	12	multi	none	5
Tatung	42"	TPD4201S	M5	25	multi	5.6mm ID	91
Tatung	46"	P46CCWV	M6	12	multi	none	5
Tatung	46"	P46T	M6	12	multi	none	5
Tatung	42"	PTSW4200U	M8	40	none	8.7mm ID	91
Techview	42"	42WS90E	M4	12	multi	none	7
Thompson	42"	42WS93E	M4	12	multi	none	7
Thompson	32"	32HL66	M6	12	none	none	
Toshiba	32"	32HL67	M6	12	none	none	
Toshiba	32"	32HL83	M6	25	multi	8.7mm ID	
Toshiba	32"	32HL84	M4	12	multi	none	6
Toshiba	32"	32HLX95	M4	12	multi	none	6
Toshiba	32"	32LV67	M6	12	none	none	
Toshiba	37"	37HL17	M6	12	none	none	
Toshiba	37"	37HL67	M6	12	none	none	
Toshiba	40"	40RF350U	M6	12	none	none	
Toshiba	42"	42HL167	M6	12	none	none	11
Toshiba	42"	42HL66	M8	25	none	8.7mm ID	
Toshiba	42"	42HL67	M6	12	none	none	11
Toshiba	42"	42HP66	M8	25	none	8.7mm ID	
Toshiba	42"	42 HP82	M4	12	multi	none	7
Toshiba	42"	42 HP83	M8	15	none	none	
Toshiba	42"	42 HP95	M5	12	multi	none	
Toshiba	42"	42DPC85	M5	12	multi	none	
Toshiba	42"	42HP84	M8	25	none	8.7mm ID	
Toshiba	42"	42LX177	M6	12	none	none	11
Toshiba	42"	42LX196	M6	12	none	none	11
Toshiba	42"	P42LHA	M6	12	none	none	
Toshiba	42"	PD-42W1	M8	40	none	8.7mm ID	
Toshiba	47"	47HL167	M6	12	none	none	
Toshiba	50"	50HP16	M8	25	none	8.7mm ID	
Toshiba	50"	50 HP81	M8	40	none	8.7mm ID	
Toshiba	50"	50 HP82	M4	12	multi	none	7
Toshiba	50"	50HPX95	M5	12	multi	none	
Toshiba	50"	Plasma 5000	M8	16	none	none	
Toshiba	52"	52HL167	M8	25	none	8.7mm ID	
Translux	42"	Vizio P42ED	M8	misc	none	multiple	13 & 91
TV Logic	46"	LVM-460W	M6	12	none	none	
V Inc. (Vizio)	37"	VX37L	M8	25	none	none	
V Inc. (Vizio)	42"	DDK420PDP	M4	12	multi	none	
V Inc. (Vizio)	42"	P42HD	M8	misc	none	multiple	13 & 91
V Inc. (Vizio)	42"	P42HDe	M8	misc	none	multiple	13 & 91
V Inc. (Vizio)	42"	VS42LF	M8	16	none	none	
V Inc. (Vizio)	42"	VU42LF	M8	16	none	none	
V Inc. (Vizio)	46"	P4	M6	12	multi	none	5
V Inc. (Vizio)	47"	GV47LFHDTV	M8	25	none	8.7 MM ID	
V Inc. (Vizio)	50"	JV50P	M8	15	none	none	
V Inc. (Vizio)	50"	P50HD	M8	15	none	none	
V Inc. (Vizio)	52"	GV52LFHDTV10A	M8	25	none	8.7 MM ID	
Vernex	60"	DDK600PDP	M8	15	none	none	
Vernex	42"	VP42	M4	12	multi	none	7
Vidikron	42"	VP42HD	M4	12	multi	none	7
Vidikron	42"	VP50	M4	12	multi	none	7
Vidikron	32"	N3200w	M4	12	multi	none	91
Viewsonic	32"	N3206W	M6	12	none	none	11
Viewsonic	32"	N3235W	M6	12	none	none	
ViewSonic	32"	N3250W	M6	12	multi	none	
Viewsonic	32"	N3251W	M6	12	none	none	
Viewsonic	32"	N3252W	M6	12	none	none	
Viewsonic	32"	N3260W	M6	12	none	none	11
Viewsonic	37"	N3735W	M6	12	none	none	
Viewsonic	42"	CD4220	M6	12		none	
Viewsonic	42"	N4200W	M6	12		none	
Viewsonic	42"	N4210W	M6	12		none	
ViewSonic	42"	N4280p	M6	12	none	none	
Viewsonic	42"	N4285P	M6	12		none	

See chart below to determine the fasteners to use with your screen. If your screen has a note in the far right column, then reference it on the last page.

Manufacturer	ScreenSize	Model	ScrewSize	ScrewLength	Washer	Spacer	Notes
ViewSonic	42"	N4251W	M6	12	multi	none	
Viewsonic	42"	ND4200-LS	M8	40	none	8.7mm ID	
Viewsonic	42"	VPW 4255	M6	12	multi	none	
Viewsonic	42"	VPW425	M8	40	none	8.7mm ID	91
Viewsonic	42"	VPW450HD	M8	40	none	8.7mm ID	91
Viewsonic	46"	CD4620	M6	12		none	
Viewsonic	50"	VPW500	M8	16	none	none	
Viewsonic	50"	VPW505	M8	40	none	15.9mm tall	1
Viewsonic	32"	LTV-32w1	M4	12	multi	none	6
Westinghouse	32"	LC32	M4	12	multi	none	6
Westinghouse	32"	SK-32H240D	M4	12	washer	none	6
Westinghouse	32"	SK-32H590D	M4	12	washer	none	6
Westinghouse	32"	W3213 HD	M4	12	washer	none	6
Westinghouse	37"	LVM-37w1	M4	12	multi	none	6
Westinghouse	40"	SK-40H520S	M4	12	washer	none	6
Westinghouse	40"	SK-40H590S	M4	12	washer	none	6
Westinghouse	42"	SK-42H330S	M4	12	washer	none	6
Westinghouse	42"	TX-42F430S	M4	12	washer	none	6
Westinghouse	47"	TX-47F430S	M6	12	none	none	11
Winbook	42"	PDM-4210	M6	12	multi	none	
Yamaha	32"	Z32LZ5R	M4	12	multi	none	6
Zenith	37"	Z37LZ5D	M4	12	multi	none	6
Zenith	40"	DPDP40V	M5	25	multi	5.6mm ID	
Zenith	40"	H40DVPDP	M5	25	multi	5.6mm ID	
Zenith	40"	P40V22	M5	25	multi	5.6mm ID	
Zenith	40"	P40V24	M5	25	multi	5.6mm ID	
Zenith	42"	P42W22B	M5	25	multi	5.6mm ID	91
Zenith	42"	P42W22H	M5	25	multi	5.6mm ID	91
Zenith	42"	P42W24B	M5	25	multi	5.6mm ID	91
Zenith	42"	P42W24P	M5	25	multi	5.6mm ID	91
Zenith	42"	P42W34/34H	M5	25	multi	5.6mm ID	91
Zenith	42"	P42W34P	M5	25	multi	5.6mm ID	91
Zenith	42"	P42W46X	M5	25	multi	5.6mm ID	91
Zenith	42"	Z42P3	M6	12	multi	none	11
Zenith	50"	P50W26B	M5	25	multi	5.6mm ID	91
Zenith	50"	P50W28B/P	M5	25	multi	5.6mm ID	91
Zenith	50"	P50W38/38H/38P	M5	25	multi	5.6mm ID	91
Zenith	60"	DPDP60W	M8	15	none	none	
Zenith	60"	P60W26P/H	M8	15	none	none	
Zenith	60"	P60W36	M8	15	none	none	
Zenith	60"	P60W38/38H	M8	15	none	none	

NOTES (only look at the note that applies to your screen from the previous table)

* The mount includes 12.7mm tall spacers

- 1 All hardware may not be included. If you are missing the additional fasteners needed for your screen, then please contact Customer Care at 1-800-729-0307.
- 2 If back of screen has a bumpout at bottom, then you may need to shift the brackets up so mount would miss it.
- 3 Remove the knobs on the back of the screen. Attach the mounting brackets to the mounting holes where the knobs used to be.
- 4 Use outer-most mounting holes
- 5 Remove cover, knob, handle, or original screws from TV before attaching bracket.
- 6 If back of screen has a bumpout, or if mounting holes lie in pockets, then use M4 X 25 mm screw with 12.7mm tall spacers
- 7 If screw is too small, then use M5 X 12 mm screw.
- 8 If mounting holes lie inside pockets, then use M8x25mm screws with 8.7mm ID spacers
- 9 If screen bumpout hits mount, then contact Customer Care for 15.9mm tall spacers (*not included*)
- 10 Use M8 x 25mm screws with 8.7mm ID spacers for top mounting holes. Use M8 x 40mm screws with 8.7mm ID spacers for bottom mounting holes
- 11 If screw gets less than 3 threads of engagement, then try the next longer length screw. If all longer lengths have been tried, and there is still less than 3 threads of engagement, then contact Customer Care for assistance.
- 12 If back of screen has a bumpout, then remove it, or contact Customer Care for 15.9mm tall spacers and M5x40mm screws (both are *not included*). Stack the spacers with 12.7mm tall spacers that come with the mount.
- 13 Each top mounting hole requires stacking an 8.7mm ID spacer with a 15.9mm tall spacer (*not included*) and an M8x40mm screw. Bottom threaded holes require 15.9mm tall spacers (*not included*) and M8x25mm screws.
- 14 Remove all accessories, such as the D-Box, from the back of the screen. If you want to attach these accessories directly to the screen, then call Customer Care for a dedicated mount or mount accessory.
- 15 If you get less than 4 full threads of engagement, then contact Customer Care for M4x16mm screws (*not included*)
- 16 If you get less than 4 full threads of engagement, then contact Customer Care for M5x16mm screws (*not included*)
- 17 If you get less than 3 full threads of engagement, then contact Customer Care for M6x16mm screws (*not included*)
- 18 If you get less than 3 full threads of engagement, then contact Customer Care for M8x30mm screws (*not included*)
- 19 Top mounting holes require these fasteners, which are *not included* : M4x20mm, 6.4mm tall spacer, and M4 large OD washer. Place them in this order: bracket to washer to spacer to screen.
- 20 No Security. Requires (4) 1/4-20x1/2" screws and (4) 1/4-20 hexnuts (*not included*). Refer to Bobcat instruction for removing the Mounting Plate from the back of the screen. Attach the mounting brackets to the Bobcat Mounting Plate using the 1/4-20 screws and hexnuts, then install that back onto screen. For security option, contact Customer Care for a dedicated mount.
- 21 If any mounting hole lies in a dimple, then place a 3.2mm thick washer (*not included*) in the dimple.
- 22 If any mounting hole lies in a dimple, then place an M5 flat washer (*not included*) in the dimple. 50" screens require 2 more M5x12 screws.
- 23 Requires stacking 31.8mm tall spacers (*not included*) and 12.7mm tall spacers
- 24 Requires M4x35mm screws and 19.1mm tall spacers (both are *not included*). Remove the cable cover from the back of the screen first. Shift the brackets down so that they are out of view when looking down from the front of the screen.
- 90 Hardware specifications are not currently available. Please contact Customer Care at 1-800-729-0307 and ask for technical support to assist in the determination of your specific hardware configuration.
- 91 May require deep brackets.