

Installation and Assembly - Plasma Adapter bracket for Planar® Systems 42" PDP-42B Plasma Monitor


Model: PLNR42



This product is intended for use with UL Listed products and must be installed by a qualified professional installer.

Parts List

PART #	QTY.	DESCRIPTION
AA 200-1228	1	adapter bracket
BB 520-1161	6	M5 x 16 mm socket pin screw
CC 590-1132	6	retaining spacer
DD 560-9646	1	4 mm allen wrench




Some parts may appear slightly different than illustrated.

- Place six M5 socket pin screws (BB) through adapter plate (AA) and six retaining spacers (CC) as shown below. Attach adapter plate (AA) to back of plasma by tightening M5 socket pin screws (BB) using 4 mm allen wrench (DD).

See accompanying instruction sheet for assembly of mount and attachment of adapter plate to mount.

⚠ WARNING

- Do not overtighten. Overtightening may cause permanent damage to screen. Torque to 26-35 in. / lb. (30-40 kg / cm).



Side View

