




# Assembly & Installation Instructions: Standard with Slide Platform Mounting for the Following:



## Parts Included



## Hardware Kit #AKP-HDWR-BB



## Required

Adjustable Keyboard Arm


## Tools Required

Socket wrench with 3/8" socket

**Note:** Mount your adjustable keyboard arm to your worksurface using the instructions that came with your adjustable keyboard arm.


## 1 Mount Keyboard Platform to Arm

- a** Align the threaded studs on the bottom of the Standard with Slide (A) with the mounting holes in the keyboard arm.
- b** Attach with four 3/8" #10-32 Keps Nuts (B) and tighten securely.



## 2 Place Mouse Pad

Peel the backing off the Mouse Pad (C) and place in either the left or right hand location. The Mouse Pad provides improved traction and pointing accuracy. It can be repositioned by simply peeling it up and placing it elsewhere.




### 3 Route Keyboard and Mouse Cords on Keyboard Platform

- a** Place keyboard cord under overhang at either end of Optimizer. Place mouse cord under overhang closest to the mouse.

**Note:** The CB-180S25 does not include the Optimizer, so two extra Cord Clips (D) are included to guide cords down either the left or right side of the arm.



- b** Route the mouse cord into the slot at back rear corner of the Optimizer. Be sure to leave enough slack in cord to allow for unrestricted movement of the mouse.



### 4 Attach Cord Clips and Rout Cords on Arm & Under Worksurface


**Note:** Make sure your keyboard arm is fully extended before routing your cables.

Place one Cord Clip (D) on the side of the arm mechanism. Place the other Cord Clip on the rear of the track. Do the opposite side in the same fashion if cords run down the left side.



### 5 Apply Friction Pads or Hook & Loop Squares

Place Friction Pads (F) on the bottom surface of your keyboard to keep it in place, if necessary. The Friction Pads will keep your keyboard from sliding when the platform is angled.



### 6 Consult the User Guide for your Pinnacle Arm

Go to [www.workriteergo.com/instructions](http://www.workriteergo.com/instructions) to find the Pinnacle Arm User Guide for instructions on how to set up this product for ideal ergonomic benefit.

