

ARMS

ARM TYPE	LOW	HIGH	GROUP	FRAME	PAD
KR21	10	12.25	1	ARFKR21	ARPKR21
KR25	10.5	13.25	1	ARFKR25	ARPKR25-N
KR25M	10.5	13.25	1	ARFKR25	ARPNTS R/L
KR32	9.25	11.75	1	ARFKR21	ARPKR32
KR200	9.25	12	1	ARFKR200	ARPKR25-N
KR200M	9.25	12	1	ARFKR200	ARPNTS R/L
KR200-45	10.75	13.5	1	ARFKR200	ARPJR45 R/L
KR200-65	10.25	13	1	ARFKR200	ARPJR65 R/L
KR240M	8.5	11.25	1	ARFKR240	ARPNTS R/L
KR251M	10.5	13.25	1	ARFKR240/ARXRP51 R/L	ARPNTS R/L
KR300	10.5	13.25	1	ARFKR300	ARPKR300
KR300M	10.75	13.5	1	ARFKR300	ARPNTS R/L
KR300-45	12	14.75	1	ARFKR300	ARPJR45 R/L
KR300-65	11.5	14.25	1	ARFKR300	ARPJR65 R/L
KR445	9.75	12.5	1	ARFKR240	ARPJR45 R/L
KR465	8.75	11.5	1	ARFKR240	ARPJR65 R/L
KR500	10.5	13.25	1	ARFKR200	ARPJR50 R/L
KR540	9.5	12.25	1	ARFKR240	ARPJR50 R/L
KR600	11	13.75	1	ARFKR300	ARPJR50 R/L
JR75	10.5	15	1	ARFJR70	ARPJR77(FABRIC)
JR77	10.5	15	1	ARFJR77	ARPJR77
JR77M	10.5	15	1	ARFJR77	ARPNTS R/L
JR90	10.5	13	1	ARFJR70	ARPJR90
JRBN	11	13.5	1	ARFJRPD	ARPJR77
JRPD	11	13.5	1	ARFJRPD-LA	ARPNTS R/L
JRPD(old)	12.5	15.5	1		
ETR1	11.5	11.5	1		
KR48	12	12	1	ARPKR48	
JR30M	9.25	13.5	4	ARFJR40-LOW	ARPNTS R/L
JR39	9.75	14	4	ARFJR39-NB R/L	ARPJR37
JR39M	9.75	14	4	ARFJR39-NB R/L	ARPNTS R/L
JR40M	9.5	13.5	4	ARFJR40-LOW	ARPNTS R/L
JR49	10.5	14.75	4	ARFJR39-NB R/L	ARPJR45 R/L
JR59	10.25	10.5	4	ARFJR39-NB R/L	ARPJR50 R/L
JR69	9.5	13.75	4	ARFJR39-NB R/L	ARPJR65 R/L
BR2	11.5	11.5	BC		
BR5*	12	14.75	BC		
BR85	11.5	11.5	BC		
BC86	11.25	11.25	BC		
ER75	10.5	15	ESD	KRFKR25	ARPJR77
ER75PU	10.5	15	ESD	ARFKR25	ARPER77

9.5 AROUND

From the bottom of the arm frame to the top of the pad.

* When using on the BC85 switch the bracket
 ** All heights are approximate. Seat heights vary