



## Split-Level-36

## Task Table



## **Assembly Instructions**



Missing Parts or UPS Damaged Parts For Your Convenience you can EMAIL us at <u>furniture@baltinc.com</u> 24HOURS 7 DAYS A WEEK


Should you require assistance during assembly, please call our Customer Service Department Monday - Friday 8 a.m. - 5 p.m. Central Standard Time 1-800-749-2258


Do not use unless all screws are tight. At least every six months, check all screws to be sure they are tight. If parts are missing, broken, damaged, or worn, stop use of the product until repairs are made by your dealer using factory authorized parts.

## Split-Level-36 Assembly Diagram




READ THROUGH INSTRUCTIONS FROM BEGINNING TO END <u>BEFORE</u> STARTING TO ASSEMBLE UNIT.





- 11.) Place the CPU Platform (P10) with the insert nuts facing up. Attach 2 each CPU Feet (P9) using 4 each (A2) screws. (Finger tighten only)
- 12.) Attach 1 each CPU Rail (P8) to the CPU Platform (P10) using 2 each (A1) screws. (Finger tighten only)
- 13.) Attach 2 each Glides (F) to the 2 Feet (P9) as shown in illustration #5.
- 14.) Attach 1 each CPU Assembly to the outside of Leg Receiver (P7) using 2 Screws (A1) as shown in illustration #6.

(Tighten all the screws at this time using Allen Wrench (G)).



A2

A2

**P**9


F

F



15.)To install Grommet (E), separate parts and press Grommet Sleeve in rectangular opening in Monitor Platform (P1) as shown in illustration #6.

Snap 2 plastic Caps over top of Sleeve as shown in illustration #6.





The Balt product you have purchased is guaranteed against material and workmanship defects. This guarantee extends 1 year from date of purchase. Should this product fail to function satisfactorily under normal use due to defect or imperfection, the defective part or product will be replaced. Damage caused by common carriers during shipment is not included in this guarantee.

This guarantee sets forth all applicable guarantees and remedies. No other warranty, expressed or implied shall apply. Failure to follow instructions found in Important Information Section of Owner Sheet shall void the guarantee. Consequential or incidental damages and or costs are not refundable.

