


Open enclosed parts and tool assembly package. The package will include...

- (9) Torx bit screws (T-15)
- (1) Mounting template
- (1) Torx bit screwdriver
- (1) 1/4" x 2" lag bolt
- (1) 1/4" x 2 1/4" machined bolt
- (1) Pan washer
- (1) Lock washer
- (1) Thimble
- (1) Bolt cap




1 Supplied Hardware



Lay the faceplate on a smooth surface ensuring the dock connector opening is at the bottom.

2



Route power cable through the Archelon as shown*.


3 OPTIONAL POWER CORD INSTALLATION



Carefully place the iPad®, face down, onto the faceplate making sure the Apple® logo is as shown.


(Numbers will be explained in step 6)

4



Carefully place Archelon assembly w/power cord* onto faceplate as shown.


5



Carefully fasten the Archelon assembly to the faceplate using the supplied (T-15) Torx screws (8). Plug dock connector into iPad®.


(Note: Tighten hand tight in a crisscross pattern. Note numbering sequence in step 4)

6




Using the supplied mounting template tape into place. Also make sure there is a 110v power source*. Keep a minimum of 4" clear space (away from walls other obstructions) to allow the Archelon to operate in its full range of motion.

7




Using a 3/4" drill bit (for thimble hole only!) drill through the surface. Using a 1/4" drill bit drill bolt hole.
(Note: Make sure correct drill bit is used for your specific surface)

8 3/4" & 1/4" drill bits required (not supplied)




Insert power cord (USB connector first) into thimble hole.

9 3/4" & 1/4" drill bits required (not supplied)



Firmly press the thimble into base making sure the slot aligns with the notches as shown. Route power cord as shown and install into the thimble hole.

10



Install lag bolt (or machined bolt w/supplied pan washer, lock washer & nut) as shown.

11



Press the bolt cap into place and you're done!

12

****The power cord is required to operate the iPad® continuously.
Not using the power cord will required the iPad® to be recharged when needed.***

