


## Installation and Assembly: SHARP 108 CART/STAND

Model: DS039




NOTE: Read entire instruction sheet before you start installation and assembly. Max Load Capacity: 500 lb (227 kg)


## **A WARNING**

- Do not begin to install your Peerless product until you have read and understood the instructions and warnings contained in this Installation Sheet. If you have any questions regarding any of the instructions or warnings, please call Peerless customer care at 1-800-865-2112.
- This product should only be installed by a qualified professional.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.
- Never exceed the Maximum Load Capacity of 500 lb (227 kg).
- Always use an assistant or mechanical lifting equipment to safely lift and position equipment.
- Tighten screws firmly, but do not overtighten. Overtightening can damage the items, greatly reducing their holding power.


Tools Needed for Assembly • phillips screwdriver • 3/8" socket wrench




Slide left screen mount tube (A) over right foot assembly (D). Fasten using two M10 screws with lock washers & flat washers (K) as shown. Repeat for left foot assembly (C).




Attach two horizontal supports (**E**) to left foot assembly (**D**) using eight 1/4-20 x 1/2" phillips screws (**J**), 1/4"SAE flat washers (**I**) and 1/4" split washers (**H**).





- Attach right foot assembly (**C**) to horizontal supports (**E**) using eight 1/4-20 x 1/2" phillips screws (**J**), 1/4" SAE flat washers (**I**) and 1/4" split washers (**H**).
- E J C
- Place horizontal tube supports (**E**) between screen mount tubes (**A and B**). Attach horizontal tubes (**E**) using sixteen 1/4-20 x 1/2" phillips screws (**J**), 1/4"SAE flat washers (**I**) and 1/4" split washers (**H**).



Attach four casters (**P**) to left and right foot assemblies (**C** and **D**) using sixteen M8 x 25 mm pan phillips screws (**M**), split washers (**O**) and 5/16" SAE flat washers (**N**).









Thread eight M10 screws with lock washers and flat washers (**K**) into right screen tube (**B**) and left screen tube (**A**) leaing 1/8' gap as shown in detail 1.

Attach two adapter brackets (L) to screen using eight M16 x 30 mm socket head screws (Q) and eight 1/2" flat washers (R).






4 of 5

ISSUED: 02-24-09 SHEET #: 090-9168-1



Hook screen into exposed M10 screws with lock washers & flat washers (**K**) of left and right screen mount tubes (**A and B**). Secure all screws.





Attach two caps (**G**) to the ends of left and right screen mount assemblies (**A and B**). Use four M10 screws with lock washers and flat washers (**K**) screw to secure two adapter bracket (**L**).

