



U4ia™

Knee-tilt

1. Back Height

2. Seat Height

3. Seat Angle

6. Arm Height

5. Seat Slider (depth)

4. Seat Tilt Tension



U4ia™ - Knee-tilt

1. **Back Height** - Slowly lift the back until you have the appropriate lumbar support. If the back is too high, lift the back all the way up and then lower to the first position.
2. **Seat Height** - Lift the lever and lift your weight to raise the seat to the desired position. To lower the seat, lift the lever while remaining seated.
3. **Seat Angle** - Pull the lever out, away from the seat to allow the seat to rock freely. To lock the seat into position, push the lever back in.
4. **Seat Tilt Tension** - From in front of the chair turn the knob to the right to increase tension or turn the knob to the left to decrease tension.
5. **Seat Slider (depth)** - With your back against the backrest, lift the bar under the front edge of seat to disengage the lock and slide the seat to your desired position. Release the bar to lock the seat in place.
6. **Arm Height** - Press button under arm pad to adjust height until your arms are properly supported.