Installation and Assembly - Solid•Point™ Flat Panel Straight Column Mount

Model: PLCM 1, PLCM UNL



This product is intended for use with UL Listed products and must be installed by a qualified professional installer.

Maximum Load Capacity: 225 lb (102.3 kg)

Read instruction sheet before you start installation and assembly.



TABLE OF CONTENTS


Installations

Installing Flat Panel Straight Column Mount to ceiling .. page 3

Applications

WARNING


 Installer must verify that the ceiling will safely support the combined weight of all attached equipment and hardware.




Before you begin, make sure all parts shown are included with your product.

PARTS LIST

			PLCM 1 PLCM UNL
	Description	Qty	Part #
Α	ceiling arm box	1	201-1062
В	tilt bracket	1	200-1552
С	33" support pipe	1	139-1088
D	retaining collar	1	1800-375
Е	M5 x .8 x 10 mm penta-pin™ screw	4	505-9010
F	2.875 OD x 2.125 ID x .062 H fiber washer	1	540-9432
G	M10 x 1.5 x 15 mm penta-pin screw	8	520-9263
Н	M10 x 2" penta-pin tool	1	520-9260
ı	M5 x 1" penta-pin tool	1	520-9249
J	M5 x .8 x 8 mm phillips Type F screw	4	520-1167






Note: Some parts may not appear exactly as illustrated.


Thread support pipe (**C**) into threaded fitting in ceiling plate (**not included**). Tighten - four or five complete turns - leaving slot aligned with one small hole in the side of the ceiling plate threaded fitting. Insert and tighten one M5 x .8 x 10 mm penta-pin screw provided with ceiling plate as shown. Use the M5 penta-pin tool (**I**) to tighten screw. BY HAND, insert four M10 x 1.5 x 15 mm penta-pin screws (**G**) into threaded holes in the sides of ceiling arm box (**A**). Leave approximately 1/4" of exposed thread. Slide ceiling arm box (**A**) and fiber washer (**F**) onto end of support pipe (**C**). Thread retaining collar (**D**) onto threaded end of support pipe (**C**). Tighten - four or five complete turns. Slide ceiling arm box (**A**) down so that it is on top of retaining collar (**D**). Insert and tighten one M5 x .8 x 10 mm penta-pin screw (**E**) into retaining collar (**D**) as shown. Insert one M5 penta-pin screw (**E**) through the tab on the

Note: ADJ or EXT extension columns can be used in combination with, or in place of support pipe (**C**) to achieve different lengths.

back of ceiling arm box (A). Use M5 penta-pin tool (I) to tighten screw just enough to stabilize support pipe (C).



Note: Refer to adapter plate instruction sheet for attachment of adapter plate to plasma before proceeding with step 2.



3


Hang tilt bracket ($\bf B$) onto ceiling arm box ($\bf A$). Adjust tilt as desired and tighten four M10 x 1.5 x 15 mm penta-pin screws ($\bf G$) securely using M10 penta-pin tool ($\bf H$).


A WARNING

• For a safe assembly be sure to fully tighten four screws (**G**).

A WARNING

Do not mount PLCM UNL in portrait orientation.
 Mounting PLCM UNL in portrait orientation may result in product failure.





PORTRAIT
(Not to be used with UNL models)

4 of 5


ISSUED:08-20-02 SHEET #: 200-9404-8 02-16-06

Note: Refer to adapter bracket instruction sheet for attachment of adapter bracket to LCD screen before proceeding with step 2.




Attach tilt bracket (B) to adapter bracket using four M5 x 8 mm phillips screws (J).

Note: Do not use M5 x 6 mm screws that are included with the adapter bracket.



Note: Screen and adapter plate may appear different than illustrated.

Hang tilt bracket (**B**) onto ceiling arm box (**A**). Adjust tilt as desired and tighten four M10 x 1.5 x 15 mm penta-pin screws (**G**) securely using M10 penta-pin tool (**H**).



5 of 5

ISSUED:08-20-02 SHEET #: 200-9404-8 02-16-06