
INSTALLATION INSTRUCTIONS



IN-WALL ACCESSORY BOX





DISCLAIMER

Milestone AV Technologies, Inc., and its affiliated corporations and subsidiaries (collectively, "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.

IMPORTANT WARNINGS AND CAUTIONS!

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.


WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

CAUTION: This equipment must be installed and assembled by qualified service personnel in accordance with local building codes.

WARNING: Failure to provide adequate structural strength for this accessory can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this accessory is attached can support the combined weight of the box and all equipment not to exceed 10 lbs (4.5 kg). **IMPORTANT !** : SUITABLE FOR USE IN OTHER ENVIRONMENTAL AIR SPACE IN ACCORDANCE WITH SECTION 300.22, (C) OF THE NATIONAL ELECTRICAL CODE.

- **NOTE:** The equipment shall be installed and assembled by qualified service personnel.
- **NOTE:** Knockouts are provided for ease of installation. Any unused knockouts that have been punched are to be closed up with a metal plug.
- **NOTE:** The maximum specified ambient temperature of the cabinet system is 40° 120°F (4° 49°C).
- **NOTE:** Spacings Minimum spacings between the Accessories and components and the housing for Information Technology Communication Equipment shall be maintained for safe operation of the equipment when installed in accordance with the National Electric Code, ANSI/NFPA 70-1999. Refer to communication equipment manufacturer's specifications for minimum spacings.
- **NOTE:** This In-Wall Cabinet System is for use with ITE or Audio/Video equipment only.

DIMENSIONS




LEGEND


	Tighten Fastener
C	Apretar elemento de fijación
	Befestigungsteil festziehen
	Apertar fixador
	Serrare il fissaggio
	Bevestiging vastdraaien
	Serrez les fixations
	Loosen Fastener
C	Aflojar elemento de fijación
	Befestigungsteil lösen
	Desapertar fixador
	Allentare il fissaggio
	Bevestiging losdraaien
	Desserrez les fixations
æ	Phillips Screwdriver
	Destornillador Phillips
	Kreuzschlitzschraubendreher
	Chave de fendas Phillips
	Cacciavite a stella
	Kruiskopschroevendraaier
	Tournevis à pointe cruciforme

	Pencil Mark
	Marcar con lápiz
	Stiftmarkierung
	Marcar com lápis
	Segno a matita
	Potloodmerkteken
	Marquage au crayon
	Drill Hole
	Perforar
	Bohrloch
	Fazer furo
	Praticare un foro
	Gat boren
	Percez un trou
	Hex-Head Wrench
	Llave de cabeza hexagonal
	Sechskantschlüssel
\bigcirc	Chave de cabeça sextavada
	Chiave esagonale
	Zeskantsleutel
	Clé à tête hexagonale
$\mathbf{\hat{\mathbf{A}}}$	Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada Chiave esagonale Zeskantsleutel

TOOLS REQUIRED FOR INSTALLATION



PARTS



INSTALLATION

The PAC522 is intended for use in installations where the wall surface has not been finished and the structure (studs) is exposed. The PAC522 requires the wall be finished around the opening of the box after the box has been installed.

WARNING: IMPROPER INSTALLATION CAN RESULT DEATH OR SERIOUS PERSONAL INJURY! This accessory should be installed by qualified personnel.

PAC522 Site Preparation

Locate and Prepare Mounting Site


1. Identify a suitable wall location for the accessory.

IMPORTANT ! : The PAC522 is designed for in-wall installation between two wood or steel studs, 16" on center. Inadequate space will remain on each side between studs for electrical wires/cables, plumbing, ductwork, or insulation. Locate accordingly!

WARNING: ELECTRICAL SHOCK HAZARD! CUTTING OR DRILLING INTO ELECTRICAL WIRES OR CABLES CAN CAUSE DEATH OR SERIOUS PERSONAL INJURY! ALWAYS make certain area behind mounting surfaces is free of electrical wires and cables before cutting, drilling, or installing fasteners.

WARNING: EXPLOSION AND FIRE HAZARD! CUTTING OR DRILLING INTO GAS PLUMBING CAN CAUSE DEATH OR SERIOUS PERSONAL INJURY! ALWAYS make certain area behind mounting surfaces is free of gas, water, waste, or any other plumbing before cutting, drilling, or installing fasteners.

- 2. Using a stud sensor, locate and mark studs.
- 3. Center and level housing between marked studs.
- 4. Using housing as a template, draw pencil line completely around housing.
- **NOTE:** Housing is designed to fit between and directly against two adjacent wall studs.
- Using a measuring tool, measure the marked area and compare to the dimensions below. If measurements match, continue to Step 6. If not, adjust markings to match dimensions below. (See Figure 1)
- 6. Cut drywall on *outside* edge of line and remove.





Accessory Box Installation

1. Position PAC522 (A) in desired mounting location.




Figure 2

WARNING: ELECTRICAL SHOCK HAZARD! CUTTING OR DRILLING INTO ELECTRICAL WIRES OR CABLES CAN CAUSE DEATH OR SERIOUS PERSONAL INJURY! ALWAYS make certain area behind mounting surfaces is free of electrical wires and cables before cutting, drilling, or installing fasteners.

2. Secure accessory box to studs by:

WOOD STUD:

- 1. Drill four 3/16" dia. pilot holes in studs at mounting holes. (See Figure 4)
- Install four M7 x 40mm Allen head connector screws (D) into pilot holes using an M4 Allen head drill bit (F). (See Figure 4)

STEEL STUD:

- 1. Drill four 3/16" dia. pilot holes in studs at mounting holes. (See Figure 4)
- Install four 1/4" countersunk finishing washers (B) and four 1/4" x 2" Phillips flat head self drilling screws (E) into pilot holes. (See Figure 4)
- **NOTE:** When installing PAC522 in Configuration B the quantity of hardware changes to three for both wood and steel stud installations.

DANGER: IMPROPER WIRING CAN LEAD TO DEATH OR SEVERE PERSONAL INJURY! Grounding must be installed by qualified personnel using a UL Recognized No. 12AWG Green and Yellow grounding wire connected to grounding lug on mount.




Figure 3





Figure 4

Cable Management

Use the wire tie clips (C), as necessary, for cable management. (See Figure 5)







Chief Manufacturing, a products division of Milestone AV Technologies

8807-002010 Rev00 ©2009 Milestone AV Technologies, a Duchossois Group Company www.chiefmfg.com 07/09

USA/Internatio	nal A	8401 Eagle Creek Parkway, Savage, MN 55378
	Р	800.582.6480 / 952.894.6280
	F	877.894.6918 / 952.894.6918
Europe	Α	Fellenoord 130 5611 ZB EINDHOVEN, The Netherlands
	Р	+31 (0)40 2668620
	F	+31 (0)40 2668615
Asia Pacific	Α	Room 24F, Block D, Lily YinDu International Building
		LuoGang, BuJi Town, Shenzhen, CHINA.
	深圳市	布吉罗岗村百合银都国际大厦D栋24F
	Р	+86-755-8996 9226

F +86-755-8996 9217

