Front edge of worksurface (dashed line)



Note: Front edge of track may be recessed up to 2" from front edge of worksurface for increased stowability.


Installation Template: Leader 1

See page 2 for Parts Included and Tools Required for this installation.




ergonomics[®]

Note: Make sure this template is printed at 100% scale. Select "None" in Page Scaling menu in printer dialog box.



Assembly & Installation Instructions: Keyboard Arm with Nylon Glide Track

Workrite **WISE** ergonomics[®]




Worksurface Adjustable Keyboard Platform

#2 Phillips screwdriver or drill/driver Tape

Continued from other side.

B Install Pilot Screws in Pilot Holes

Install two #12 × 3/4" Phillips Screws (B) into Pilot Holes. Leave a gap of approximately 1/8" between the head of the screw and worksurface.



Mount Track


- **4.1** Remove the two $\#10-24 \times \frac{1}{2}$ " Screws (C) then the Track Cover (D). Slide Arm off Track.
- 4.2 Slide Track on Pilot Screws. Tighten Pilot Screws securely.
- **4.3** Drill ¹/₈" diameter x ³/₄" deep pilot holes at marked locations. Install remaining #12 × 3/4" Wood Screws (B) into Pilot Holes.




CAUTION!

Do not drill all the way through the worksurface! You may wish to mark your drill bit so you do not drill any further than 34".

Tighten Securely.





5 Install Arm

- **5.1** Replace Arm on Track.
- **5.2** Replace the two $\#10-24 \times \frac{1}{2}$ " Screws (C).
- **5.3** Tighten screws securely.

